

BASIC FUNCTION LIST

GM

Autoboss Scanner: V30
Version: V2.5
Date: 2008-10-23

1996—2003 year

Year	Model	System	Engine Type	Read DTC	Erase DTC	Data Stream	Function Test	ID Info
	Passenger Car	Powertrain	(4) 2.2L L4 LN2	√	√	√	√	√
			(T) 2.4L L4 LD9	√	√	√	√	√
			(M) 3.1L V6 L82	√	√	√	√	√
			(X) 3.4L V6 LQ1	√	√	√	√	√
			(1) 3.8L V6 L67	√	√	√	√	√
			(K) 3.8L V6 L36	√	√	√	√	√
			(C) 4.0L V8 L47	√	√	√	√	√
			(W) 4.3L V8 L99	√	√	√	√	√
			(9) 4.6L V8 L37	√	√	√	√	√
			(Y) 4.6L V8 LDB	√	√	√	√	√
			(5) 5.7L V8 LT4	√	√	√	√	√
			(P) 5.7L V8 LT1	√	√	√	√	√
			(T)		BODY			
CHASI								

<http://www.autoboss.net>

Autoboss Scanner Function List

1996	LD Trk, MPV , Incompl ete	(4)2.2L L4 LN2\S\4 Speed Automatic	√	√	√	√	√
		(E)3.4L V6 LA1	√	√	√		
		(W)4.3L V6 L35\C\4 Speed Automatic\Under 8600 GVW	√	√			
		(W)4.3L V6 L35\C\Manual\Under 8600 GVW	√	√			
		(W)4.3L V6 L35\G\4 Speed Automatic\Under 8600 GVW	√	√			
		(W)4.3L V6 L35\G\4 Speed Automatic\Equal to or Over 8600 GVW	√	√			
		(W)4.3L V6 L35\K\4 Speed Automatic\ Under 8600 GVW	√	√			
		(W)4.3L V6 L35\K\Manual\ Under 8600 GVW	√	√			
		(W)4.3L V6 L35\L	√	√			
		(W)4.3L V6 L35\M	√	√			
		(W)4.3L V6 L35\P\4 Speed Automatic\ Equal to or Over 8600 GVW					
		(W)4.3L V6 L35\P\4 Speed Automatic\Manual\ Equal to or Over 8600 GVW	√	√			
		(W)4.3L V6 L35\S\4 Speed Automatic	√	√			
		(W)4.3L V6 L35\S\Manual	√	√			
		(W)4.3L V6 L35\T\4 SPEED AUTOMATIC	√	√			
		(W)4.3L V6 L35\T\Manual	√	√			
		(X)4.3L V6 LF6\S\4 SPEED AUTOMATIC	√	√	√	√	
		(X)4.3L V6 LF6\S\Manual	√	√	√	√	
		(X)4.3L V6 LF6\T\4 SPEED AUTOMATIC	√	√	√	√	
		(X)4.3L V6 LF6\T\Manual	√	√	√	√	
(M)5.0L V8 L30\C\4 Speed Automatic	√	√	√	√			
(M)5.0L V8 L30\C\Manual	√	√	√	√			

[http: //www.autoboss.net](http://www.autoboss.net)

Autoboss Scanner Function List

		Powertrain	(M)5.0L V8 L30\G\4 Speed Automatic	✓	✓	✓	✓	
			(M)5.0L V8 L30\K\4 Speed Automatic	✓	✓	✓	✓	
			(M)5.0L V8 L30\K\Manual	✓	✓	✓		
			(F)6.5L V8 L65\C\4 Speed Automatic	✓	✓	✓	✓	✓
			(F)6.5L V8 L65\C\Manual	✓	✓	✓	✓	✓
			(F)6.5L V8 L65\G\4 Speed Automatic	✓	✓	✓	✓	✓
			(F)6.5L V8 L65\K\4 Speed Automatic	✓	✓	✓	✓	✓
			(F)6.5L V8 L65\K\Manual	✓	✓	✓	✓	✓
			(F)6.5L V8 L65\P\4 Speed Automatic	✓	✓	✓	✓	✓
			(F)6.5L V8 L65\P\Manual	✓	✓	✓	✓	✓
			(S)6.5L V8 L56\C\4 Speed Automatic	✓	✓	✓	✓	✓
			(S)6.5L V8 L56\K\4 Speed Automatic	✓	✓	✓	✓	✓
			(J)7.4L V8 L29\C\4 Speed Automatic\California Emissions\Without Air Pump	✓	✓	✓	✓	
			(J)7.4L V8 L29\C\4 Speed Automatic\California Emissions\With Air Pump	✓	✓	✓	✓	
			(J)7.4L V8 L29\C\4 Speed Automatic\Federal Emissions	✓	✓	✓	✓	
			(J)7.4L V8 L29\C\Manual	✓	✓	✓	✓	
			(J)7.4L V8 L29\G\4 Speed Automatic\ California Emissions\ Without Air Pump	✓	✓	✓	✓	
			(J)7.4L V8 L29\G\4 Speed Automatic\ California Emissions\ With Air Pump	✓	✓	✓	✓	
			(J)7.4L V8 L29\G\4 Speed Automatic\ Federal Emissions	✓	✓	✓	✓	
			(J)7.4L V8 L29\K\4 Speed Automatic\ California Emissions\ Without Air Pump	✓	✓	✓	✓	

<http://www.autoboss.net>

Autoboss Scanner Function List

			(J)7.4L V8 L29\K\4 Speed Automatic\ California Emissions\ With Air Pump	√	√	√	√	
			(J)7.4L V8 L29\K\4 Speed Automatic\ Federal Emissions	√	√	√	√	
			(J)7.4L V8 L29\K\Manual	√	√	√	√	
			(J)7.4L V8 L29\P\4 Speed Automatic\ California Emissions\ Without Air Pump	√	√	√	√	
			(J)7.4L V8 L29\P\4 Speed Automatic\ California Emissions\ With Air Pump	√	√	√	√	
			(J)7.4L V8 L29\P\4 Speed Automatic\ Federal Emissions	√	√	√	√	
		Body	[T]	√	√	√		
			[C]	√	√	√		
			[E]	√	√	√		
			[G]	√	√	√		
			[J]	√	√	√		
			[K]	√	√	√		
			[L]	√	√	√		
			[M]	√	√	√		
			[S]	√	√	√		
			[U]	√	√	√		
		Chassis	ABS	√	√	√	√	
	Saturn	Chassis	ABS	√	√	√	√	
1997	Passenger Car	Powertrain	(4) 2.2L L4 LN2	√	√	√	√	√
			(T) 2.4L L4 LD9	√	√	√	√	√
			(R) 3.0L V6 L81	√	√	√	√	√

<http://www.autoboss.net>

Autoboss Scanner Function List

		(M) 3.1L V6 L82	√	√	√	√	√
		(X) 3.4L V6 LQ1	√	√	√	√	√
		(1) 3.8L V6 L67	√	√	√	√	√
		(K) 3.8L V6 L36	√	√	√	√	√
		(C) 4.0L V8 L47	√	√	√	√	√
		(9) 4.6L V8 L37	√	√	√	√	√
		(Y) 4.6L V8 LD8	√	√	√	√	√
		(G) 5.7L V8 LS1	√	√	√	√	√
		(P) 5.7L V8 LT1	√	√	√	√	√
		(5) Electric Motor LN1	√	√	√	√	√
	BODY	[C]	√	√	√	√	√
		[E]	√	√	√	√	√
		[K]	√	√	√	√	√
	Chasis						
LD Trk, MPV , Incompl ete	Powertr ain	(4)2.2L L4 LN2-->[S]-->4 Speed Automatic	√	√	√	√	
		(4)2.2L L4 LN2-->[S]-->Manual	√	√	√	√	
		(E)3.4L V6 LA1	√	√	√	√	
		(W)4.3L V6 L35-->[C]-->4 Speed Automatic	√	√			
		(W)4.3L V6 L35-->[C]--> Manual	√	√			
		(W)4.3L V6 L35-->[G]-->Under 8600 GVW	√	√			
		(W)4.3L V6 L35-->[G]-->Equal to or Over 8600 GVW	√	√			
		(W)4.3L V6 L35-->[K]-->4 Speed Automatic	√	√			

<http://www.autoboss.net>

Autoboss Scanner Function List

	(W)4.3L V6 L35-->[K]-->Manual	√	√			
	(W)4.3L V6 L35-->[L]	√	√			
	(W)4.3L V6 L35-->[M]	√	√			
	(W)4.3L V6 L35-->[P]-->4 Speed Automatic	√	√			
	(W)4.3L V6 L35-->[P]-->Manual	√	√			
	(W)4.3L V6 L35-->[S]-->4 Speed Automatic	√	√			
	(W)4.3L V6 L35-->[S]-->Manual	√	√			
	(W)4.3L V6 L35-->[T]-->4 Speed Automatic	√	√			
	(W)4.3L V6 L35-->[T]-->Manual	√	√			
	(X)4.3L V6 LF6a [S]-->4 Speed Automatic	√	√	√	√	
	(X)4.3L V6 LF6a [S]-->Manual	√	√	√	√	
	(X)4.3L V6 LF6a [T]-->4 Speed Automatic	√	√	√	√	
	(X)4.3L V6 LF6a [T]-->Manual	√	√	√	√	
	(M)5.0L V8 L30-->[C]-->4 Speed Automatic	√	√	√	√	
	(M)5.0L V8 L30-->[C]-->Manual	√	√	√	√	
	(M)5.0L V8 L30-->[G]	√	√	√	√	
	(M)5.0L V8 L30-->[K]-->4 Speed Automatic	√	√	√	√	
	(M)5.0L V8 L30-->[K]-->Manual	√	√	√	√	
	(R)5.7L V8 L31-->[C]-->4 Speed Automatic-->Under 8600 GVW	√	√			
	(R)5.7L V8 L31-->[C]-->4 Speed Automatic-->Equal to or Over 8600 GVW	√	√			
	(R)5.7L V8 L31-->[C]-->Manual-->Under 8600 GVW	√	√			
	(R)5.7L V8 L31-->[C]-->Manual-->Equal to or Over 8600 GVW	√	√			
	(R)5.7L V8 L31-->[G]-->Under 8600 GVW	√	√			

<http://www.autoboss.net>

Autoboss Scanner Function List

	(R)5.7L V8 L31-->[G]-->Equal to or Over 8600 GVW	√	√			
	(R)5.7L V8 L31-->[K]-->4 Speed Automatic-->Under 8600 GVW	√	√			
	(R)5.7L V8 L31-->[K]-->4 Speed Automatic-->Equal to or Over 8600 GVW	√	√			
	(R)5.7L V8 L31-->[K]-->Manual-->Under 8600 GVW	√	√			
	(R)5.7L V8 L31-->[K]-->Manual-->Equal to or Over 8600 GVW	√	√			
	(R)5.7L V8 L31-->[P]-->4 Speed Automatic	√	√			
	(R)5.7L V8 L31-->[P]-->Manual	√	√			
	(R)5.7L V8 L31 Bi-Fuel	√	√	√	√	√
	(F)6.5L V8 L65-->[C]-->4 Speed Automatic	√	√	√	√	√
	(F)6.5L V8 L65-->[C]-->Manual	√	√	√	√	√
	(F)6.5L V8 L65-->[G]-->4 Speed Automatic	√	√	√	√	√
	(F)6.5L V8 L65-->[K]-->4 Speed Automatic	√	√	√	√	√
	(F)6.5L V8 L65-->[K]-->Manual	√	√	√	√	√
	(F)6.5L V8 L65-->[P]-->4 Speed Automatic	√	√	√	√	√
	(F)6.5L V8 L65-->[P]-->Manual	√	√	√	√	√
	(S)6.5L V8 L56-->[C]-->4 Speed Automatic	√	√	√	√	√
	(S)6.5L V8 L56-->[K]-->4 Speed Automatic	√	√	√	√	√
	(J)7.4L V8 L29-->[C]-->4 Speed Automatic	√	√	√	√	
	(J)7.4L V8 L29-->[C]-->Manual	√	√	√	√	
	(J)7.4L V8 L29-->[G]-->4 Speed Automatic	√	√	√	√	
	(J)7.4L V8 L29-->[K]-->4 Speed Automatic	√	√	√	√	
	(J)7.4L V8 L29-->[K]-->Manual	√	√	√	√	
	(J)7.4L V8 L29-->[P]-->4 Speed Automatic	√	√	√	√	

<http://www.autoboss.net>

Autoboss Scanner Function List

		Chassis	[C]\Electronic Variable Orifice	√	√	√			
			[G]\Electronic Variable Orifice	√	√	√			
			[K]\Electronic Variable Orifice	√	√	√			
			[L]\Electronic Variable Orifice	√	√	√			
			[M]\Electronic Variable Orifice	√	√	√			
			[P]\Electronic Variable Orifice	√	√	√			
			[H]\Delco/Bosch ABS/TCS	√	√	√			
		Body	[C]	√	√	√			
			[E]	√	√	√			
			[G]	√	√	√			
			[H]	√	√	√			
			[J]	√	√	√			
			[K]	√	√	√			
			[L]	√	√	√			
	Saturn	Powertrain	(7) 1.9L L4 LL0	√	√	√			
			(8) 1.9L L4 L24	√	√	√			
			Chassis	ABS	√	√	√		
	Passeng	Powertr		(4) 2.2L L4 LN2	√	√	√	√	√

<http://www.autoboss.net>

Autoboss Scanner Function List

1998	er Car	ain	(4) 2.2L L4 LN2 Bi-Fuel	√	√	√	√	√
			(T) 2.4L L4 LD9	√	√	√	√	√
			(R) 3.0L V6 L81	√	√	√	√	√
			(M) 3.1L V6 L82	√	√	√	√	√
			(1) 3.8L V6 L67	√	√	√	√	√
			(K) 3.8L V6 L36	√	√	√	√	√
			(8) 4.0L V8 - Shelby	√	√	√	√	√
			(C) 4.0L V8 L47	√	√	√	√	√
			(9) 4.6L V8 L37	√	√	√	√	√
			(Y) 4.6L V8 LD8	√	√	√	√	√
		(C) 5.7L V8 LS1	√	√	√	√	√	
		BODY	[C]	√	√	√	√	√
			[E]	√	√	√	√	√
			[J]	√	√	√	√	√
			[K]	√	√	√	√	√
	Chassis	ABS	√	√				
	LD Trk, MPV ,	Powertr ain	(4)2.2L L4 LN2-->[S]-->4 Speed Automatic-->With ECR	√	√	√	√	√
			(4)2.2L L4 LN2-->[S]-->4 Speed Automatic-->Without ECR	√	√	√	√	√
			(4)2.2L L4 LN2-->[S]-->Manual-->With ECR	√	√	√	√	√
			(4)2.2L L4 LN2-->[S]-->Manual-->Without ECR	√	√	√	√	√
(E)3.4L V6 LA1			√	√	√			
(W)4.3L V6 L35-->[C]-->4 Speed Automatic-->Under 8600 GVW			√	√				
(W)4.3L V6 L35-->[C]-->Manual			√	√				

<http://www.autoboss.net>

Autoboss Scanner Function List

Incompl ete	(W)4.3L V6 L35-->[G]-->4 Speed Automatic-->Under 8600 GVW	√	√			
	(W)4.3L V6 L35-->[G]-->4 Speed Automatic-->Equal to or Over 8600 GVW	√	√			
	(W)4.3L V6 L35-->[K]-->4 Speed Automatic-->Under 8600 GVW	√	√			
	(W)4.3L V6 L35-->[K]-->Manual	√	√			
	(W)4.3L V6 L35-->[L]-->4 Speed Automatic-->Under 8600 GVW	√	√			
	(W)4.3L V6 L35-->[M]-->4 Speed Automatic-->Under 8600 GVW	√	√			
	(W)4.3L V6 L35-->[P]-->4 Speed Automatic	√	√			
	(W)4.3L V6 L35-->[P]-->Manual	√	√			
	(W)4.3L V6 L35-->[S]-->4 Speed Automatic-->Under 8600 GVW	√	√			
	(W)4.3L V6 L35-->[S]-->Manual	√	√			
	(W)4.3L V6 L35-->[T]-->4 Speed Automatic-->Under 8600 GVW-->1 Speed Active	√	√			
	(W)4.3L V6 L35-->[T]-->4 Speed Automatic-->Under 8600 GVW-->2 Speed Active	√	√			
	(W)4.3L V6 L35-->[T]-->4 Speed Automatic-->Under 8600 GVW-->Electronic Shift/Manual Shift	√	√			
	(W)4.3L V6 L35-->[T]-->Manual-->1 Speed Active	√	√			
(W)4.3L V6 L35-->[T]-->Manual-->2 Speed Active	√	√				

<http://www.autoboss.net>

Autoboss Scanner Function List

	(W)4.3L V6 L35-->[T]-->Manual-->Electronic Shift/Manual Shift	√	√			
	(X)4.3L V6 LF6-->[S]-->4 Speed Automatic	√	√	√	√	
	(X)4.3L V6 LF6-->[S]-->Manual	√	√	√	√	
	(X)4.3L V6 LF6-->[T]-->4 Speed Automatic	√	√	√	√	
	(X)4.3L V6 LF6-->[T]-->Manual	√	√	√	√	
	(M)5.0L V8 L30-->[C]-->4 Speed Automatic	√	√	√	√	
	(M)5.0L V8 L30-->[C]-->Manual	√	√	√	√	
	(M)5.0L V8 L30-->[G]-->4 Speed Automatic	√	√	√	√	
	(M)5.0L V8 L30-->[K]-->4 Speed Automatic	√	√	√	√	
	(M)5.0L V8 L30-->[K]-->Manual	√	√	√	√	
	(R)5.7L V8 L31-->[C]-->4 Speed Automatic-->Under 8600 GVW-->Without Air Pump	√	√			
	(R)5.7L V8 L31-->[C]-->4 Speed Automatic-->Under 8600 GVW-->With Air Pump	√	√			
	(R)5.7L V8 L31-->[C]-->4 Speed Automatic-->Equal to or Over 8600 GVW	√	√			
	(R)5.7L V8 L31-->[C]-->Manual-->Under 8600 GVW	√	√			
	(R)5.7L V8 L31-->[C]-->Manual-->Equal to or Over 8600 GVW	√	√			
	(R)5.7L V8 L31-->[G]-->4 Speed Automatic-->Under 8600 GVW	√	√			
	(R)5.7L V8 L31-->[G]-->4 Speed Automatic-->Equal to or Over 8600 GVW	√	√			
	(R)5.7L V8 L31-->[K]-->4 Speed Automatic-->Under 8600 GVW-->Without Air Pump	√	√			

<http://www.autoboss.net>

Autoboss Scanner Function List

	(R)5.7L V8 L31-->[K]-->4 Speed Automatic-->Under 8600 GVW-->With Air Pump	√	√			
	(R)5.7L V8 L31-->[K]-->4 Speed Automatic-->Equal to or Over 8600 GVW	√	√			
	(R)5.7L V8 L31-->[K]-->Manual-->Under 8600 GVW	√	√			
	(R)5.7L V8 L31-->[K]-->Manual-->Equal to or Over 8600 GVW	√	√			
	(R)5.7L V8 L31-->[P]-->4 Speed Automatic	√	√			
	(R)5.7L V8 L31-->[P]-->Manual	√	√			
	(R)5.7L V8 L31 Bi-Fuel	√	√	√	√	√
	(F)6.5L V8 L65-->[C]-->4 Speed Automatic	√	√	√	√	√
	(F)6.5L V8 L65-->[C]-->Manual	√	√	√	√	√
	(F)6.5L V8 L65-->[G]-->4 Speed Automatic	√	√	√	√	√
	(F)6.5L V8 L65-->[K]-->4 Speed Automatic	√	√	√	√	√
	(F)6.5L V8 L65-->[K]-->Manual	√	√	√	√	√
	(F)6.5L V8 L65-->[P]-->4 Speed Automatic	√	√	√	√	√
	(F)6.5L V8 L65-->[P]-->Manual	√	√	√	√	√
	(S)6.5L V8 L56-->[C]-->4 Speed Automatic	√	√	√	√	√
	(S)6.5L V8 L56-->[K]-->4 Speed Automatic	√	√	√	√	√
	(B)7.4L V8 L21	√	√	√	√	√
	(J)7.4L V8 L29-->[C]-->4 Speed Automatic	√	√	√	√	
	(J)7.4L V8 L29-->[C]-->Manual	√	√	√	√	
	(J)7.4L V8 L29-->[G]-->4 Speed Automatic	√	√	√	√	
	(J)7.4L V8 L29-->[K]-->4 Speed Automatic	√	√	√	√	
	(J)7.4L V8 L29-->[K]-->Manual	√	√	√	√	
	(J)7.4L V8 L29-->[P]-->4 Speed Automatic	√	√	√	√	

<http://www.autoboss.net>

Autoboss Scanner Function List

	Chassis	\C\Under 15000 GVW\4WAL 3 Sensor	√	√	√		
		\C\Under 15000 GVW\Electronic Variable Orifice	√	√	√		
		\C\Equal to or Over 15000 GVW\Electronic Variable Orifice	√	√	√		
		\E\Electronic\4WAL 3 Sensor	√	√	√		
		\G\Electronic Variable Orifice	√	√	√		
		\H\Delco/Bosch ABS/TCS	√	√	√		
		\K\4WAL 3 Sensor	√	√	√		
		\K\Electronic Variable Orifice	√	√	√		
		\L\Electronic Variable Orifice	√	√	√		
		\M\Electronic Variable Orifice	√	√	√		
		\P\Electronic Variable Orifice	√	√	√		
		\S\4WAL 3 Sensor	√	√	√		
		\T\4WAL 3 Sensor	√	√	√		
	Body	[K]	√	√	√		
		[C]	√	√	√		
		[E]	√	√	√		
		[G]	√	√	√		
		[H]	√	√	√		
		[J]	√	√	√		
		[L]	√	√	√		
		[M]	√	√	√		
		[P]	√	√	√		
		[S]	√	√	√		
[T]	√	√	√				
[U]	√	√	√				

http: //www.autoboss.net

Autoboss Scanner Function List

			[X]	✓	✓	✓		
	Saturn	Powertrain	Automatic	✓	✓	✓		
		Chassis	ABS	✓	✓	✓	✓	
1999	Passenger Car	Powertrain	(4) 2.2L L4 LN2	✓	✓	✓	✓	✓
			(4) 2.2L L4 LN2 Alternative Fuel	✓	✓	✓	✓	✓
			(T) 2.4L L4 LD9	✓	✓	✓	✓	✓
			(R) 3.0L V6 L81	✓	✓	✓	✓	✓
			(J) 3.1L V6 LG8	✓	✓	✓	✓	✓
			(M) 3.1L V6 L82	✓	✓	✓	✓	✓
			(E) 3.4L V6 LA1	✓	✓	✓	✓	✓
			(H) 3.5L V6 LX5	✓	✓	✓	✓	✓
			(1) 3.8L V6 L67	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36	✓	✓	✓	✓	✓
			(8) 4.0L V8-Shelby	✓	✓	✓	✓	✓
			(C) 4.0L V8 L47	✓	✓	✓	✓	✓
			(9) 4.6L V8 L37	✓	✓	✓	✓	✓
			(Y) 4.6L V8 LD8	✓	✓	✓	✓	✓
		(G) 5.7L V8 LS1	✓	✓	✓	✓	✓	
		Body	[E]	✓	✓	✓	✓	✓
			[F]	✓	✓	✓	✓	✓
			[K]	✓	✓	✓	✓	✓
			[W]	✓	✓	✓	✓	✓
			Chassis	ABS	✓	✓		

<http://www.autoboss.net>

Autoboss Scanner Function List

LD Trk, MPV , Incompl ete	Powertr ain	(4)2.2L L4 LN2	√	√	√	√	√
		(E)3.4L V6 LA1	√	√	√		
		(L) 4.1L L6 LH3	√	√	√		√
		(W)4.3L V6 L35[T]-->4 Speed Automatic\Without Air Pump\1 Speed Active	√	√	√		
		(W)4.3L V6 L35[T]-->4 Speed Automatic\Without Air Pump\2 Speed Active	√	√	√		
		(W)4.3L V6 L35[T]-->4 Speed Automatic\Without Air Pump\Electronic Shift/Manual Shift	√	√	√		
		(W)4.3L V6 L35[T]-->4 Speed Automatic\With Air Pump\1 Speed Active	√	√	√		
		(W)4.3L V6 L35[T]-->4 Speed Automatic\With Air Pump\2 Speed Active	√	√	√		
		(W)4.3L V6 L35[T]-->4 Speed Automatic\With Air Pump\Electronic Shift/Manual Shift	√	√	√		
		(X)4.3L V6 LF6	√	√	√	√	
		(V) 4.8L V8 LR4	√	√	√	√	√
		(M)5.0L V8 L30	√	√	√	√	
		(T) 5.3L V8 LM7	√	√	√	√	√
		(R)5.7L V8 L31	√	√	√	√	√
		(R)5.7L V8 L31 Alternative-Fuel	√	√	√	√	√
		(U) 6.0L V8 LQ4	√	√	√	√	√
		(F)6.5L V8 L65	√	√	√	√	√
		(S)6.5L V8 L56	√	√	√	√	√
		(B)7.4L V8 L21	√	√	√	√	√

<http://www.autoboss.net>

Autoboss Scanner Function List

		(J)7.4L V8 L29	√	√	√	√	√
	Body	[K]	√	√	√		
		[C]	√	√	√		
		[E]	√	√	√		
		[G]	√	√	√		
		[H]	√	√	√		
		[J]	√	√	√		
		[L]	√	√	√		
		[M]	√	√	√		
		[S]	√	√	√		
		[T]	√	√	√		
		[U]	√	√	√		
	Chassis	\C\Under 15000 GVW\4WAL 3 Sensor	√	√	√		
		\C\Under 15000 GVW\Electronic Variable Orifice	√	√	√		
		\C\Equal to or Over 15000 GVW\Electronic Variable Orifice	√	√	√		
		\E\Electronic\4WAL 3 Sensor	√	√	√		
		\H\Delco/Bosch ABS/TCS	√	√	√		
		\J\4WAL 3 Sensor	√	√	√		
		\K\4WAL 3 Sensor	√	√	√		
		\K\Electronic Variable Orifice	√	√	√		
		\L\4WAL 3 Sensor	√	√	√		
		\M\4WAL 3 Sensor	√	√	√		
		\S\4WAL 3 Sensor	√	√	√		
	\T\4WAL 3 Sensor	√	√	√			

<http://www.autoboss.net>

Autoboss Scanner Function List

	Saturn	Powertrain	Automatic	√	√	√		
		Chassis	ABS	√	√	√	√	
2000	Passenger car	Powertrain	(H) 3.5L V6 LX5\W	√	√	√	√	√
			(H) 3.5L V6 LX5\G	√	√	√	√	√
			(4) 2.2L L4 LN2 Alternative Fuel\4 speed Automatic	√	√	√	√	√
			(J) 3.1L V6 LG8\N	√	√	√	√	√
			(J) 3.1L V6 LG8\W\Buick	√	√	√	√	√
			(J) 3.1L V6 LG8\W\Pontiac	√	√	√	√	√
			(E) 3.4L V6 LA1\N	√	√	√	√	√
			(E) 3.4L V6 LA1\W	√	√	√	√	√
			(1) 3.8L V6 L67\C	√	√	√	√	√
			(1) 3.8L V6 L67\H	√	√	√	√	√
			(1) 3.8L V6 L67\W	√	√	√	√	√
			(1) 3.8L V6 L67\2 Pontiac	√	√	√	√	√
			(1) 3.8L V6 L67\4 Buick	√	√	√	√	√
			(K) 3.8L V6 L36\C\Without Air Pump	√	√	√	√	√
			(K) 3.8L V6 L36\C\With Air Pump	√	√	√	√	√
			(K) 3.8L V6 L36\H\Without Air Pump	√	√	√	√	√
			(K) 3.8L V6 L36\H\With Air Pump	√	√	√	√	√
			(K) 3.8L V6 L36\W\Buick\Without Air Pump	√	√	√	√	√
			(K) 3.8L V6 L36\W \Buick \With Air Pump	√	√	√	√	√
			(K) 3.8L V6 L36\W \Chevrolet \Without Air Pump	√	√	√	√	√
(K) 3.8L V6 L36\W \Chevrolet \With Air Pump	√	√	√	√	√			

http: //www.autoboss.net

Autoboss Scanner Function List

		(K) 3.8L V6 L36\[W]\Pontic\Without Air Pump	✓	✓	✓	✓	✓
		(K) 3.8L V6 L36\[W] \Pontic \With Air Pump	✓	✓	✓	✓	✓
		(C) 4.0L V8 L47	✓	✓	✓	✓	✓
		(9) 4.6L V8 L37	✓	✓	✓	✓	✓
		(Y) 4.6L V8 LD8	✓	✓	✓	✓	✓
		(G) 5.7L V8 LS1\4 Speed Automatic	✓	✓	✓	✓	✓
		(G) 5.7L V8 LS1\Manual	✓	✓	✓	✓	✓
		(4) 2.2L L4 LN2 \4 speed Automatic	✓	✓	✓	✓	✓
		(4) 2.2L L4 LN2 \Manual	✓	✓	✓	✓	✓
		(T) 2.4L L4 LD9\[J]\ 4 speed Automatic	✓	✓	✓	✓	✓
		(T) 2.4L L4 LD9\[J]\ Manual	✓	✓	✓	✓	✓
		(T) 2.4L L4 LD9\[N]\ 4 speed Automatic	✓	✓	✓	✓	✓
		(T) 2.4L L4 LD9\[N]\ Manual	✓	✓	✓	✓	✓
		(T) 2.4L L4 LD9 Supercharged\ 4 speed Automatic	✓	✓	✓	✓	✓
		(T) 2.4L L4 LD9 Supercharged \ Manual	✓	✓	✓	✓	✓
	Body	[E]	✓	✓	✓	✓	✓
		[F]	✓	✓	✓	✓	✓
		[H]	✓	✓	✓	✓	✓
		[J]	✓	✓	✓	✓	✓
		[K]	✓	✓	✓	✓	✓
		[N]	✓	✓	✓	✓	✓
		[W]	✓	✓	✓	✓	✓
		[Y]	✓	✓	✓	✓	✓
	Chassis						
LD Trk,		(4)2.2L L4 LN2-->[S]-->4 Speed Automatic	✓	✓	✓	✓	✓

[http: //www.autoboss.net](http://www.autoboss.net)

Autoboss Scanner Function List

	MPV , Incompl ete	Powertr ain	(4)2.2L L4 LN2-->[S]-->Manual	√	√	√	√	√
			(5) 2.2L L4 L43-->[S]-->4 Speed Automatic	√	√	√	√	√
(5) 2.2L L4 L43-->[S]-->Manual			√	√	√	√	√	
(E)3.4L V6 LA1-->Without Air Pump			√	√	√	√	√	
(E)3.4L V6 LA1-->With Air Pump			√	√	√	√	√	
(L) 4.1L L6 LH3			√	√	√		√	
(W)4.3L V6 L35-->[C]-->4 Speed Automatic-->Without Air Pump			√	√	√	√	√	
(W)4.3L V6 L35-->[C]-->4 Speed Automatic-->With Air Pump			√	√	√	√	√	
(W)4.3L V6 L35-->[C]-->Manual			√	√	√	√	√	
(W)4.3L V6 L35-->[G]-->Under 8600 GVW-->4 Speed Automatic-->Without Air Pump			√	√	√	√	√	
(W)4.3L V6 L35-->[G]-->Under 8600 GVW-->4 Speed Automatic-->With Air Pump	√	√	√	√	√			
(W)4.3L V6 L35-->[G]-->Equal to or Over 8600 GVW	√	√	√	√	√			
(W)4.3L V6 L35-->[K]-->4 Speed Automatic-->Without Air Pump	√	√	√	√	√			
(W)4.3L V6 L35-->[K]-->4 Speed Automatic-->With Air Pump	√	√	√	√	√			
(W)4.3L V6 L35-->[K]-->Manual	√	√	√	√	√			
[W] 4.3L V6 L35-->[L]	√	√	√	√	√			
[W] 4.3L V6 L35-->[M]	√	√	√	√	√			
[W] 4.3L V6 L35-->[P]-->4 Speed Automatic	√	√	√	√	√			
[W] 4.3L V6 L35-->[P]-->Manual	√	√	√	√	√			
[W] 4.3L V6 L35-->[S]-->4 Speed Automatic-->Without Air Pump	√	√	√	√	√			

<http://www.autoboss.net>

Autoboss Scanner Function List

		[W] 4.3L V6 L35-->[S]-->4 Speed Automatic-->With Air Pump	√	√	√	√	√
		[W] 4.3L V6 L35-->[S]-->Manual -->Without Air Pump	√	√	√	√	√
		[W] 4.3L V6 L35-->[S]-->Manual -->With Air Pump	√	√	√	√	√
		[W] 4.3L V6 L35-->[T]-->4 Speed Automatic-->Without Air Pump-->1 Speed Active	√	√	√	√	√
		[W] 4.3L V6 L35-->[T]-->4 Speed Automatic-->Without Air Pump-->2 Speed Active	√	√	√	√	√
		[W] 4.3L V6 L35-->[T]-->4 Speed Automatic-->Without Air Pump-->Electronic Shift/Manual Shift	√	√	√	√	√
		[W] 4.3L V6 L35-->[T]-->4 Speed Automatic-->With Air Pump-->1 Speed Active	√	√	√	√	√
		[W] 4.3L V6 L35-->[T]-->4 Speed Automatic-->With Air Pump-->2 Speed Active	√	√	√	√	√
		[W] 4.3L V6 L35-->[T]-->4 Speed Automatic-->With Air Pump-->Electronic Shift/Manual Shift	√	√	√	√	√
		[W] 4.3L V6 L35-->[T]-->Manual -->Without Air Pump-->1 Speed Active	√	√	√	√	√
		[W] 4.3L V6 L35-->[T]-->Manual -->Without Air Pump-->2 Speed Active	√	√	√	√	√
		[W] 4.3L V6 L35-->[T]-->Manual -->Without Air Pump-->Electronic Shift/Manual Shift	√	√	√	√	√
		[W] 4.3L V6 L35-->[T]-->Manual -->With Air Pump-->1 Speed Active	√	√	√	√	√

<http://www.autoboss.net>

Autoboss Scanner Function List

		[W] 4.3L V6 L35-->[T]-->Manual -->With Air Pump-->2 Speed Active	√	√	√	√	√
		[W] 4.3L V6 L35-->[T]-->Manual -->With Air Pump-->Electronic Shift/Manual Shift	√	√	√	√	√
		[X] 4.3L V6 LF6-->[S]-->4 Speed Automatic-->Without Air Pump	√	√	√	√	√
		[X] 4.3L V6 LF6-->[S]-->4 Speed Automatic-->With Air Pump	√	√	√	√	√
		[X] 4.3L V6 LF6-->[S]-->Manual -->Without Air Pump	√	√	√	√	√
		[X] 4.3L V6 LF6-->[S]-->Manual -->With Air Pump	√	√	√	√	√
		[X] 4.3L V6 LF6-->[T]-->4 Speed Automatic-->Without Air Pump	√	√	√	√	√
		[X] 4.3L V6 LF6-->[T]-->4 Speed Automatic-->With Air Pump	√	√	√	√	√
		[X] 4.3L V6 LF6-->[T]-->Manual -->Without Air Pump-->1 Speed Active	√	√	√	√	√
		[X] 4.3L V6 LF6-->[T]-->Manual -->Without Air Pump-->2 Speed Active	√	√	√	√	√
		[X] 4.3L V6 LF6-->[T]-->Manual -->Without Air Pump-->Electronic Shift/Manual Shift	√	√	√	√	√
		[X] 4.3L V6 LF6-->[T]-->Manual -->With Air Pump-->1 Speed Active	√	√	√	√	√
		[X] 4.3L V6 LF6-->[T]-->Manual -->With Air Pump-->2 Speed Active	√	√	√	√	√

<http://www.autoboss.net>

Autoboss Scanner Function List

		[X] 4.3L V6 LF6-->[T]-->Manual -->With Air Pump-->Electronic Shift/Manual Shift	✓	✓	✓	✓	✓
		[V] 4.8L V8 LR4-->[C]-->4 Speed Automatic-->Without Air Pump-->Without Traction Control	✓	✓	✓	✓	✓
		[V] 4.8L V8 LR4-->[C]-->4 Speed Automatic-->Without Air Pump-->With Traction Control	✓	✓	✓	✓	✓
		[V] 4.8L V8 LR4-->[C]-->4 Speed Automatic-->With Air Pump-->Without Traction Control	✓	✓	✓	✓	✓
		[V] 4.8L V8 LR4-->[C]-->4 Speed Automatic-->With Air Pump-->With Traction Control	✓	✓	✓	✓	✓
		[V] 4.8L V8 LR4-->[C]-->Manual	✓	✓	✓	✓	✓
		[V] 4.8L V8 LR4-->[K]-->4 Speed Automatic-->Without Air Pump	✓	✓	✓	✓	✓
		[V] 4.8L V8 LR4-->[K]-->4 Speed Automatic-->With Air Pump	✓	✓	✓	✓	✓
		[V] 4.8L V8 LR4-->[K]-->Manual	✓	✓	✓	✓	✓
		(M)5.0L V8 L30	✓	✓	✓	✓	
		[T] 5.3L V8 LM7-->[C]-->Without Air Pump-->Without Traction Control	✓	✓	✓	✓	✓
		[T] 5.3L V8 LM7-->[C]-->Without Air Pump-->With Traction Control	✓	✓	✓	✓	✓
		[T] 5.3L V8 LM7-->[C]-->With Air Pump-->Without Traction Control	✓	✓	✓	✓	✓
		[T] 5.3L V8 LM7-->[C]-->With Air Pump-->With Traction Control	✓	✓	✓	✓	✓

<http://www.autoboss.net>

Autoboss Scanner Function List

	[T] 5.3L V8 LM7-->[K]-->Without Air Pump	✓	✓	✓	✓	✓
	[T] 5.3L V8 LM7-->[K]-->With Air Pump	✓	✓	✓	✓	✓
	[R] 5.7L V8 L31-->[C]-->Under 8600 GVW-->4 Speed Automatic-->Without Air Pump	✓	✓	✓	✓	✓
	[R] 5.7L V8 L31-->[C]-->Under 8600 GVW-->4 Speed Automatic-->With Air Pump	✓	✓	✓	✓	✓
	[R] 5.7L V8 L31-->[C]-->Under 8600 GVW-->Manual	✓	✓	✓	✓	✓
	[R] 5.7L V8 L31-->[C]-->Equal to or Over 8600 GVW-->4 Speed Automatic	✓	✓	✓	✓	✓
	[R] 5.7L V8 L31-->[C]-->Equal to or Over 8600 GVW-->Manual	✓	✓	✓	✓	✓
	[R] 5.7L V8 L31-->[G]-->Under 8600 GVW-->4 Speed Automatic-->Without Air Pump	✓	✓	✓	✓	✓
	[R] 5.7L V8 L31-->[G]-->Under 8600 GVW-->4 Speed Automatic-->With Air Pump	✓	✓	✓	✓	✓
	[R] 5.7L V8 L31-->[G]-->Equal to or Over 8600 GVW	✓	✓	✓	✓	✓
	[R] 5.7L V8 L31-->[K]-->Under 8600 GVW-->4 Speed Automatic-->Without Air Pump	✓	✓	✓	✓	✓
	[R] 5.7L V8 L31-->[K]-->Under 8600 GVW-->4 Speed Automatic-->With Air Pump	✓	✓	✓	✓	✓
	[R] 5.7L V8 L31-->[K]-->Under 8600 GVW-->Manual	✓	✓	✓	✓	✓
	[R] 5.7L V8 L31-->[K]-->Equal to or Over 8600 GVW-->4 Speed Automatic	✓	✓	✓	✓	✓
	[R] 5.7L V8 L31-->[K]-->Equal to or Over 8600 GVW-->Manual	✓	✓	✓	✓	✓

<http://www.autoboss.net>

Autoboss Scanner Function List

	[R]	5.7L V8 L31-->	[P]-->	4 Speed Automatic	√	√	√	√	√
	[R]	5.7L V8 L31-->	[P]-->	Manual	√	√	√	√	√
	(R)	5.7L V8 L31		Alternative-Fuel	√	√			
	[U]	6.0L V8 LQ4-->	[C]-->	4 Speed Automatic-->	√	√	√	√	√
				Without Traction Control					
	[U]	6.0L V8 LQ4-->	[C]-->	4 Speed Automatic-->	√	√	√	√	√
				With Traction Control					
	[U]	6.0L V8 LQ4-->	[C]-->	Manual	√	√	√	√	√
	[U]	6.0L V8 LQ4-->	[K]-->	4 Speed Automatic	√	√	√	√	√
	[U]	6.0L V8 LQ4-->	[K]-->	Manual	√	√	√	√	√
	[F]	6.5L V8 L65-->	[C]-->	4 Speed Automatic	√	√	√	√	√
	[F]	6.5L V8 L65-->	[C]-->	Manual	√	√	√	√	√
	[F]	6.5L V8 L65-->	[G]-->	4 Speed Automatic	√	√	√	√	√
	[F]	6.5L V8 L65-->	[K]-->	4 Speed Automatic	√	√	√	√	√
	[F]	6.5L V8 L65-->	[K]-->	Manual	√	√	√	√	√
	[F]	6.5L V8 L65-->	[P]-->	4 Speed Automatic	√	√	√	√	√
	[F]	6.5L V8 L65-->	[P]-->	Manual	√	√	√	√	√
	(B)	7.4L V8 L21			√	√	√	√	
	[J]	7.4L V8 L29-->	[C]-->	4 Speed Automatic	√	√	√	√	√
	[J]	7.4L V8 L29-->	[C]-->	Manual	√	√	√	√	√
	[J]	7.4L V8 L29-->	[G]-->	4 Speed Automatic	√	√	√	√	√
	[J]	7.4L V8 L29-->	[K]-->	4 Speed Automatic	√	√	√	√	√
	[J]	7.4L V8 L29-->	[K]-->	Manual	√	√	√	√	√
	[J]	7.4L V8 L29-->	[P]-->	4 Speed Automatic	√	√	√	√	√
	Body	[K]			√	√	√		

http: //www.autoboss.net

Autoboss Scanner Function List

		[C]	✓	✓	✓		
		[E]	✓	✓	✓		
		[G]	✓	✓	✓		
		[H]	✓	✓	✓		
		[J]	✓	✓	✓		
		[L]	✓	✓	✓		
		[M]	✓	✓	✓		
		[S]	✓	✓	✓		
		[T]	✓	✓	✓		
		[U]	✓	✓	✓		
		[X]	✓	✓	✓		
	Chassis	\E\Gasoline	✓	✓	✓		
		\E\Electric\4WAL 3 Sensor	✓	✓	✓		
		\E\Electric\Auto Disconnect	✓	✓	✓		
		\H\DRP/ABS/TCS	✓	✓	✓		
		\H\Magna Steer\Diagnostics	✓	✓	✓		
		\H\Rear Integration Module\diagnostics	✓	✓	✓		
		\J\4WAL 3 Sensor	✓	✓	✓		
		\K\4WAL 3 Sensor	✓	✓	✓		
		\K\Electronic Variable Orifice	✓	✓	✓		
		\L\4WAL 3 Sensor	✓	✓	✓		
		\M\4WAL 3 Sensor	✓	✓	✓		
		\S\4WAL 3 Sensor	✓	✓	✓		
		\T\4WAL 3 Sensor	✓	✓	✓		
Saturn	Powertr	[7] 1.9L L4 LL0	✓	✓	✓		

<http://www.autoboss.net>

Autoboss Scanner Function List

		ain	[8] 1.9L L4 L24	✓	✓	✓		
			[F] 2.2L L4 L61	✓	✓	✓		
		BODY	J	✓	✓	✓		
			Z	✓	✓	✓		
2001	Passenger Car	Powertrain	(H) 3.5L V6 LX5\W	✓	✓	✓	✓	✓
			(H) 3.5L V6 LX5\G	✓	✓	✓	✓	✓
			(4) 2.2L L4 LN2 Alternative Fuel\4 speed Automatic	✓	✓	✓	✓	✓
			(J) 3.1L V6 LG8\N	✓	✓	✓	✓	✓
			(J) 3.1L V6 LG8\W\Buick	✓	✓	✓	✓	✓
			(J) 3.1L V6 LG8\W\Pontiac	✓	✓	✓	✓	✓
			(E) 3.4L V6 LA1\N	✓	✓	✓	✓	✓
			(E) 3.4L V6 LA1\W	✓	✓	✓	✓	✓
			(1) 3.8L V6 L67\C	✓	✓	✓	✓	✓
			(1) 3.8L V6 L67\H	✓	✓	✓	✓	✓
			(1) 3.8L V6 L67\W	✓	✓	✓	✓	✓
			(1) 3.8L V6 L67\2 Pontiac	✓	✓	✓	✓	✓
			(1) 3.8L V6 L67\4 Buick	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\C\Without Air Pump	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\C\With Air Pump	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\H\Without Air Pump	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\H\With Air Pump	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\W\Buick\Without Air Pump	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\W \Buick \With Air Pump	✓	✓	✓	✓	✓
(K) 3.8L V6 L36\W \Chevrolet \Without Air Pump	✓	✓	✓	✓	✓			

http: //www.autoboss.net

Autoboss Scanner Function List

		(K) 3.8L V6 L36[W] \Chevrolet \With Air Pump	✓	✓	✓	✓	✓
		(K) 3.8L V6 L36[W]\Pontic\Without Air Pump	✓	✓	✓	✓	✓
		(K) 3.8L V6 L36[W] \Pontic \With Air Pump	✓	✓	✓	✓	✓
		(C) 4.0L V8 L47	✓	✓	✓	✓	✓
		(9) 4.6L V8 L37	✓	✓	✓	✓	✓
		(Y) 4.6L V8 LD8	✓	✓	✓	✓	✓
		(G) 5.7L V8 LS1\4 Speed Automatic	✓	✓	✓	✓	✓
		(G) 5.7L V8 LS1\Manual	✓	✓	✓	✓	✓
		(S) 5.7L V8 LS6	✓	✓	✓	✓	✓
		(4) 2.2L L4 LN2 \4 speed Automatic	✓	✓	✓	✓	✓
		(4) 2.2L L4 LN2 \Manual	✓	✓	✓	✓	✓
		(T) 2.4L L4 LD9[J] \ 4 speed Automatic	✓	✓	✓	✓	✓
		(T) 2.4L L4 LD9[J] \ Manual	✓	✓	✓	✓	✓
		(T) 2.4L L4 LD9[N] \ 4 speed Automatic	✓	✓	✓	✓	✓
		(T) 2.4L L4 LD9[N] \ Manual	✓	✓	✓	✓	✓
		(T) 2.4L L4 LD9 Supercharged \ 4 speed Automatic	✓	✓	✓	✓	✓
		(T) 2.4L L4 LD9 Supercharged \ Manual	✓	✓	✓	✓	✓
	Body	[C]	✓	✓	✓	✓	✓
		[E]	✓	✓	✓	✓	✓
		[F]	✓	✓	✓	✓	✓
		[G]	✓	✓	✓	✓	✓
		[H]	✓	✓	✓	✓	✓
		[J]	✓	✓	✓	✓	✓
		[K]	✓	✓	✓	✓	✓
		[N]	✓	✓	✓	✓	✓

[http: //www.autoboss.net](http://www.autoboss.net)

Autoboss Scanner Function List

		[W]	✓	✓	✓	✓	✓
		[Y]	✓	✓	✓	✓	✓
	Chassis	ABS	✓	✓			
LD Trk, MPV , Incompl ete	Powertr ain	Alternative-Fuels	✓	✓			
		(5) 2.2L L4 L43-->[S]→4 speed	✓	✓	✓	✓	✓
		(5) 2.2L L4 L43-->[S]→Manual	✓	✓	✓	✓	✓
		[E] 3.4L V6 LA1-->Without Air Pump-->Without All Wheel Drive	✓	✓	✓		✓
		[E] 3.4L V6 LA1-->Without Air Pump-->With All Wheel Drive	✓	✓	✓		✓
		[E] 3.4L V6 LA1-->With Air Pump-->Without All Wheel Drive	✓	✓	✓		✓
		[E] 3.4L V6 LA1-->With Air Pump-->With All Wheel Drive	✓	✓	✓		✓
		[W] 4.3L V6 L35-->Under 8600 GVW-->4 Speed Automatic-->1 Speed Active	✓	✓	✓	✓	✓
		[W] 4.3L V6 L35-->Under 8600 GVW-->4 Speed Automatic-->2 Speed Active	✓	✓	✓	✓	✓
		[W] 4.3L V6 L35-->Under 8600 GVW-->4 Speed Automatic-->Electronic Shift/Manual Shift	✓	✓	✓	✓	✓
		[W] 4.3L V6 L35-->Under 8600 GVW-->4 Speed Automatic-->2 Wheel Drive	✓	✓	✓	✓	✓
		[W] 4.3L V6 L35-->Under 8600 GVW-->Manual-->1 Speed Active	✓	✓	✓	✓	✓
		[W] 4.3L V6 L35-->Under 8600 GVW-->Manual-->2 Speed Active	✓	✓	✓	✓	✓

<http://www.autoboss.net>

Autoboss Scanner Function List

		[W] 4.3L V6 L35-->Equal to or Over 8600 GVW-->4 Speed Automatic-->2 Speed Active	✓	✓	✓	✓	✓
		[W] 4.3L V6 L35-->Equal to or Over 8600 GVW-->4 Speed Automatic-->Electronic Shift/Manual Shift	✓	✓	✓	✓	✓
		[W] 4.3L V6 L35-->Equal to or Over 8600 GVW-->4 Speed Automatic-->2 Wheel Drive	✓	✓	✓	✓	✓
		[W] 4.3L V6 L35-->Equal to or Over 8600 GVW-->Manual-->2 Speed Active	✓	✓	✓	✓	✓
		[W] 4.3L V6 L35-->Equal to or Over 8600 GVW-->Manual-->Electronic Shift/Manual Shift	✓	✓	✓	✓	✓
		[W] 4.3L V6 L35-->Equal to or Over 8600 GVW-->Manual-->2 Wheel Drive	✓	✓	✓	✓	✓
		[W] 4.3L V6 L35 (C/K Pickup Only)-->4 Speed Automatic-->2 Speed Active	✓	✓	✓	✓	✓
		[W] 4.3L V6 L35 (C/K Pickup Only)-->4 Speed Automatic-->Electronic Shift/Manual Shift	✓	✓	✓	✓	✓
		[W] 4.3L V6 L35 (C/K Pickup Only)-->4 Speed Automatic-->2 Wheel Drive	✓	✓	✓	✓	✓
		[W] 4.3L V6 L35 (C/K Pickup Only)-->Manual-->2 Speed Active	✓	✓	✓	✓	✓
		[V] 4.8L V8 LR4-->4 Speed Automatic-->Without Throttle-actuated Control	✓	✓	✓	✓	✓
		[V] 4.8L V8 LR4-->4 Speed Automatic-->With Throttle-actuated Control	✓	✓	✓	✓	✓
		[V] 4.8L V8 LR4-->Manual	✓	✓	✓	✓	✓

<http://www.autoboss.net>

Autoboss Scanner Function List

	(M)5.0L V8 L30	✓	✓			
	(T) 5.3L V8 LM7-->Without Throttle-actuated Control	✓	✓	✓	✓	✓
	(T) 5.3L V8 LM7-->With Throttle-actuated Control	✓	✓	✓	✓	✓
	(R)5.7L V8 L31	✓	✓			
	(U) 6.0L V8 LQ4	✓	✓	✓	✓	✓
	[U] 6.0L V8 LQ4-->Under 8600 GVW-->4 Speed Automatic-->2 Speed Active-->Without Throttle-actuated Control	✓	✓	✓	✓	✓
	[U] 6.0L V8 LQ4-->Under 8600 GVW-->4 Speed Automatic-->2 Speed Active-->With Throttle-actuated Control	✓	✓	✓	✓	✓
	[U] 6.0L V8 LQ4-->Under 8600 GVW-->4 Speed Automatic-->Electronic Shift/Manual Shift-->Without Throttle-actuated Control	✓	✓	✓	✓	✓
	[U] 6.0L V8 LQ4-->Under 8600 GVW-->4 Speed Automatic-->Electronic Shift/Manual Shift-->With Throttle-actuated Control	✓	✓	✓	✓	✓
	[U] 6.0L V8 LQ4-->Under 8600 GVW-->4 Speed Automatic-->263 NVG Transfer Case-->Without Throttle-actuated Control	✓	✓	✓	✓	✓
	[U] 6.0L V8 LQ4-->Under 8600 GVW-->4 Speed Automatic-->263 NVG Transfer Case-->With Throttle-actuated Control	✓	✓	✓	✓	✓

<http://www.autoboss.net>

Autoboss Scanner Function List

		[U] 6.0L V8 LQ4-->Under 8600 GVW-->4 Speed Automatic-->2 Wheel Drive-->Without Throttle-actuated Control	√	√	√	√	√
		[U] 6.0L V8 LQ4-->Under 8600 GVW-->4 Speed Automatic-->2 Wheel Drive-->With Throttle-actuated Control	√	√	√	√	√
		[U] 6.0L V8 LQ4-->Under 8600 GVW-->Manual -->2 Speed Active	√	√	√	√	√
		[U] 6.0L V8 LQ4-->Under 8600 GVW-->Manual -->Electronic Shift/Manual Shift	√	√	√	√	√
		[U] 6.0L V8 LQ4-->Under 8600 GVW-->Manual -->263 NVG Transfer Case	√	√	√	√	√
		[U] 6.0L V8 LQ4-->Under 8600 GVW-->Manual -->2 Wheel Drive	√	√	√	√	√
		[U] 6.0L V8 LQ4-->Equal to or Over 8600 GVW-->4 Speed Automatic-->2 Speed Active-->Without Throttle-actuated Control	√	√	√	√	√
		[U] 6.0L V8 LQ4-->Equal to or Over 8600 GVW-->4 Speed Automatic-->2 Speed Active-->With Throttle-actuated Control	√	√	√	√	√
		[U] 6.0L V8 LQ4-->Equal to or Over 8600 GVW-->4 Speed Automatic-->Electronic Shift/Manual Shift-->Without Throttle-actuated Control	√	√	√	√	√

<http://www.autoboss.net>

Autoboss Scanner Function List

		[U] 6.0L V8 LQ4-->Equal to or Over 8600 GVW-->4 Speed Automatic-->Electronic Shift/Manual Shift-->With Throttle-actuated Control	✓	✓	✓	✓	✓
		[U] 6.0L V8 LQ4-->Equal to or Over 8600 GVW-->4 Speed Automatic-->263 NVG Transfer Case-->Without Throttle-actuated Control	✓	✓	✓	✓	✓
		[U] 6.0L V8 LQ4-->Equal to or Over 8600 GVW-->4 Speed Automatic-->263 NVG Transfer Case-->With Throttle-actuated Control	✓	✓	✓	✓	✓
		[U] 6.0L V8 LQ4-->Equal to or Over 8600 GVW-->4 Speed Automatic-->2 Wheel Drive-->Without Throttle-actuated Control	✓	✓	✓	✓	✓
		[U] 6.0L V8 LQ4-->Equal to or Over 8600 GVW-->4 Speed Automatic-->2 Wheel Drive-->With Throttle-actuated Control	✓	✓	✓	✓	✓
		[U] 6.0L V8 LQ4-->Equal to or Over 8600 GVW-->Manual-->2 Speed Active	✓	✓	✓	✓	✓
		[U] 6.0L V8 LQ4-->Equal to or Over 8600 GVW-->Manual-->Electronic Shift/Manual Shift	✓	✓	✓	✓	✓
		[U] 6.0L V8 LQ4-->Equal to or Over 8600 GVW-->Manual-->263 NVG Transfer Case	✓	✓	✓	✓	✓
		[F] 6.5L V8 L65-->[C]-->4 Speed Automatic	✓	✓	✓	✓	✓
		[F] 6.5L V8 L65-->[C]-->Manual	✓	✓	✓	✓	✓
		[F] 6.5L V8 L65-->[G]-->4 Speed Automatic	✓	✓	✓	✓	✓
		[F] 6.5L V8 L65-->[K]-->4 Speed Automatic	✓	✓	✓	✓	✓

<http://www.autoboss.net>

Autoboss Scanner Function List

		[F] 6.5L V8 L65-->[K]-->Manual	✓	✓	✓	✓	✓
		[F] 6.5L V8 L65-->[P]-->4 Speed Automatic	✓	✓	✓	✓	✓
		(1) 6.6L V8 LB7 Diesel-->5 Speed Automatic	✓	✓	✓	✓	✓
		(1) 6.6L V8 LB7 Diesel-->Manual	✓	✓	✓	✓	✓
		[G] 8.1L V8 L18-->4 Speed Automatic-->2 Speed Active	✓	✓	✓	✓	✓
		[G] 8.1L V8 L18-->4 Speed Automatic-->263 NVG Transfer Case	✓	✓	✓	✓	✓
		[G] 8.1L V8 L18-->4 Speed Automatic-->2 Wheel Drive	✓	✓	✓	✓	✓
		[G] 8.1L V8 L18-->5 Speed Automatic-->263 NVG Transfer Case	✓	✓	✓	✓	✓
		[G] 8.1L V8 L18-->5 Speed Automatic-->2 Wheel Drive	✓	✓	✓	✓	✓
		[G] 8.1L V8 L18-->Manual -->2 Speed Active	✓	✓	✓	✓	✓
		[G] 8.1L V8 L18-->Manual -->263 NVG Transfer Case	✓	✓	✓	✓	✓
		[G] 8.1L V8 L18-->Manual -->2 Wheel Drive	✓	✓	✓	✓	✓
		[G] 8.1L V8 L18 3500 HD Only-->4 Speed Automatic	✓	✓	✓	✓	✓
		[G] 8.1L V8 L18 3500 HD Only-->Manual	✓	✓	✓	✓	✓
	chassis	\E\4WAL 3 Sensor	✓	✓	✓		
		\H\DRP/ABS/TCS	✓	✓	✓		
		\H\Magna Steer\Diagnostics	✓	✓	✓		
		\H\Rear Integration Module\diagnostics	✓	✓	✓		
		\J\4WAL 3 Sensor"	✓	✓	✓		
		\K\4WAL 3 Sensor	✓	✓	✓		
		\K\Electronic Variable Orifice	✓	✓	✓		
		\L\4WAL 3 Sensor	✓	✓	✓		
		\M\4WAL 3 Sensor	✓	✓	✓		

http: //www.autoboss.net

Autoboss Scanner Function List

			\S\4WAL 3 Sensor	✓	✓	✓			
			\T\4WAL 3 Sensor	✓	✓	✓			
		Body		[K]	✓	✓	✓		
				[A]	✓	✓	✓		
				[B]	✓	✓	✓		
				[C]	✓	✓	✓		
				[G]	✓	✓	✓		
				[H]	✓	✓	✓		
				[J]	✓	✓	✓		
				[L]	✓	✓	✓		
				[M]	✓	✓	✓		
				[P]	✓	✓	✓		
				[S]	✓	✓	✓		
				[T]	✓	✓	✓		
				[U]	✓	✓	✓		
			[X]	✓	✓	✓			
	Saturn	Powertrain	[7]	1.9L L4 LL0	✓	✓	✓		
			[8]	1.9L L4 L24	✓	✓	✓		
			[F]	2.2L L4 L61	✓	✓	✓		
		BODY	J		✓	✓	✓		
Z				✓	✓	✓			
Chassis		Z		✓	✓	✓			
2002	Passenger car		(4) 2.2L L4 L42 Alternative Fuel	✓	✓	✓	✓	✓	
			(F) 2.2L L4 L61\ [J] 4 speed Automatic	✓	✓	✓	✓	✓	

<http://www.autoboss.net>

Autoboss Scanner Function List

		Powertrain	(F) 2.2L L4 L61\[J]\Manual	✓	✓	✓	✓	✓
			(F) 2.2L L4 L61\[N]\4 speed Automatic	✓	✓	✓	✓	✓
			(F) 2.2L L4 L61\[N]\Manual	✓	✓	✓	✓	✓
			(J) 3.1L V6 LG8\[N]	✓	✓	✓	✓	✓
			(J) 3.1L V6 LG8\[W]\Buick	✓	✓	✓	✓	✓
			(J) 3.1L V6 LG8\[W]\Pontiac	✓	✓	✓	✓	✓
			(E) 3.4L V6 LA1\[N]	✓	✓	✓	✓	✓
			(E) 3.4L V6 LA1\[W]	✓	✓	✓	✓	✓
			(I) 3.8L V6 L67\[C]	✓	✓	✓	✓	✓
			(I) 3.8L V6 L67\[H]	✓	✓	✓	✓	✓
			(I) 3.8L V6 L67\[W]	✓	✓	✓	✓	✓
			(I) 3.8L V6 L67\[2] Pontiac	✓	✓	✓	✓	✓
			(I) 3.8L V6 L67\[4] Buick	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\[C]\Without Air Pump	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\[C]\With Air Pump	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\[H]\Without Air Pump	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\[H]\With Air Pump	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\[W]\Buick\Without Air Pump	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\[W] \Buick \With Air Pump	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\[W] \Chevrolet \Without Air Pump	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\[W] \Chevrolet \With Air Pump	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\[W]\Pontic\Without Air Pump	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\[W] \Pontic \With Air Pump	✓	✓	✓	✓	✓

<http://www.autoboss.net>

Autoboss Scanner Function List

		(C) 4.0L V8 L47	√	√	√	√	√
		(9) 4.6L V8 L37	√	√	√	√	√
		(Y) 4.6L V8 LD8	√	√	√	√	√
		(G) 5.7L V8 LS1\4 Speed Automatic	√	√	√	√	√
		(G) 5.7L V8 LS1\Manual	√	√	√	√	√
		(S) 5.7L V8 LS6	√	√	√	√	√
		(4) 2.2L L4 LN2 \4 speed Automatic	√	√	√	√	√
		(4) 2.2L L4 LN2 \Manual	√	√	√	√	√
		(T) 2.4L L4 LD9\J\ 4 speed Automatic	√	√	√	√	√
		(T) 2.4L L4 LD9\J\ Manual	√	√	√	√	√
		(T) 2.4L L4 LD9\N\ 4 speed Automatic	√	√	√	√	√
		(T) 2.4L L4 LD9\N\ Manual	√	√	√	√	√
		(T) 2.4L L4 LD9 Supercharged\ 4 speed Automatic	√	√	√	√	√
		(T) 2.4L L4 LD9 Supercharged \ Manual	√	√	√	√	√
	Body	[C]	√	√	√	√	√
		[E]	√	√	√	√	√
		[F]	√	√	√	√	√
		[G]	√	√	√	√	√
		[H]	√	√	√	√	√
		[J]	√	√	√	√	√
		[K]	√	√	√	√	√
		[N]	√	√	√	√	√
		[W]	√	√	√	√	√
		[Y]	√	√	√	√	√
	Chassis	ABS	√	√	√		

[http: //www.autoboss.net](http://www.autoboss.net)

Autoboss Scanner Function List

LD Trk, MPV, Incomplete	Powertrain	Alternative-Fuels	✓	✓			
		(5) 2.2L L4 L43	✓	✓	✓	✓	✓
		[E] 3. 4L V6 LA1-->Without Air Pump-->Without All Wheel Drive	✓	✓	✓	✓	✓
		[E] 3. 4L V6 LA1-->Without Air Pump-->With All Wheel Drive	✓	✓	✓	✓	✓
		[E] 3. 4L V6 LA1-->With Air Pump-->Without All Wheel Drive	✓	✓	✓	✓	✓
		[E] 3. 4L V6 LA1-->With Air Pump-->With All Wheel Drive	✓	✓	✓	✓	✓
		[S] 4. 2L L6 LL8-->4 Speed Automatic-->1 Speed Active	✓	✓	✓	✓	✓
		[S] 4. 2L L6 LL8-->4 Speed Automatic-->2 Speed Active	✓	✓	✓	✓	✓
		[S] 4. 2L L6 LL8-->4 Speed Automatic-->2 Wheel Drive	✓	✓	✓	✓	✓
		[W] 4. 3L V6 L35-->Under 8600 GVW-->4 Speed Automatic-->1 Speed Active	✓	✓	✓	✓	✓
		[W] 4. 3L V6 L35-->Under 8600 GVW-->4 Speed Automatic-->2 Speed Active	✓	✓	✓	✓	✓
		[W] 4. 3L V6 L35-->Under 8600 GVW-->4 Speed Automatic-->Electronic Shift/Manual Shift	✓	✓	✓	✓	✓
		[W] 4. 3L V6 L35-->Under 8600 GVW-->4 Speed Automatic-->2 Wheel Drive	✓	✓	✓	✓	✓
		[W] 4. 3L V6 L35-->Under 8600 GVW-->Manual-->1 Speed Active	✓	✓	✓	✓	✓
		[W] 4. 3L V6 L35-->Under 8600 GVW-->Manual-->2 Speed Active	✓	✓	✓	✓	✓

<http://www.autoboss.net>

Autoboss Scanner Function List

[W]	4.3L	V6	L35-->Under	8600	√	√	√	√	√
GVW-->Manual -->Electronic Shift/Manual Shift									
[W]	4.3L	V6	L35-->Under	8600	√	√	√	√	√
GVW-->Manual -->2 Wheel Drive									
[W]	4.3L	V6	L35-->Equal to or Over	8600	√	√	√	√	√
GVW-->4 Speed Automatic-->1 Speed Active									
[W]	4.3L	V6	L35-->Equal to or Over	8600	√	√	√	√	√
GVW-->4 Speed Automatic-->2 Speed Active									
[W]	4.3L	V6	L35-->Equal to or Over	8600	√	√	√	√	√
GVW-->4 Speed Automatic-->Electronic Shift/Manual Shift									
[W]	4.3L	V6	L35-->Equal to or Over	8600	√	√	√	√	√
GVW-->4 Speed Automatic-->2 Wheel Drive									
[W]	4.3L	V6	L35-->Equal to or Over	8600	√	√	√	√	√
GVW-->Manual -->1 Speed Active									
[W]	4.3L	V6	L35-->Equal to or Over	8600	√	√	√	√	√
GVW-->Manual -->2 Speed Active									
[W]	4.3L	V6	L35-->Equal to or Over	8600	√	√	√	√	√
GVW-->Manual -->Electronic Shift/Manual Shift									
[W]	4.3L	V6	L35-->Equal to or Over	8600	√	√	√	√	√
GVW-->Manual -->2 Wheel Drive									
[W]	4.3L	V6	L35 (C/K, G only)-->Under	8600	√	√	√	√	√
GVW-->4 Speed Automatic-->2 Speed Active									
[W]	4.3L	V6	L35 (C/K, G only)-->Under	8600	√	√	√	√	√
GVW-->4 Speed Automatic-->Electronic Shift/Manual Shift									

<http://www.autoboss.net>

Autoboss Scanner Function List

		[W] 4.3L V6 L35 (C/K, G only)-->Under 8600 GVW-->4 Speed Automatic-->2 Wheel Drive	√	√	√	√	√
		[W] 4.3L V6 L35 (C/K, G only)-->Under 8600 GVW-->Manual -->2 Speed Active	√	√	√	√	√
		[W] 4.3L V6 L35 (C/K, G only)-->Under 8600 GVW-->Manual -->Electronic Shift/Manual Shift	√	√	√	√	√
		[W] 4.3L V6 L35 (C/K, G only)-->Under 8600 GVW-->Manual -->2 Wheel Drive	√	√	√	√	√
		[W] 4.3L V6 L35 (C/K, G only)-->Equal to or Over 8600 GVW-->4 Speed Automatic-->2 Speed Active	√	√	√	√	√
		[W] 4.3L V6 L35 (C/K, G only)-->Equal to or Over 8600 GVW-->4 Speed Automatic-->Electronic Shift/Manual Shift	√	√	√	√	√
		[W] 4.3L V6 L35 (C/K, G only)-->Equal to or Over 8600 GVW-->4 Speed Automatic-->2 Wheel Drive	√	√	√	√	√
		[W] 4.3L V6 L35 (C/K, G only)-->Equal to or Over 8600 GVW-->Manual -->2 Speed Active	√	√	√	√	√
		[W] 4.3L V6 L35 (C/K, G only)-->Equal to or Over 8600 GVW-->Manual -->Electronic Shift/Manual Shift	√	√	√	√	√
		[W] 4.3L V6 L35 (C/K, G only)-->Equal to or Over 8600 GVW-->Manual -->2 Wheel Drive	√	√	√	√	√
		[X] 4.3L V6 LU3-->Under 8600 GVW-->4 Speed Automatic-->1 Speed Active	√	√	√		√
		[X] 4.3L V6 LU3-->Under 8600 GVW-->4 Speed Automatic-->2 Speed Active	√	√	√	√	√

<http://www.autoboss.net>

Autoboss Scanner Function List

[X]	4.3L V6 LU3-->Under 8600 GVW-->4 Speed Automatic-->Electronic Shift/Manual Shift	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3-->Under 8600 GVW-->4 Speed Automatic-->2 Wheel Drive	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3-->Under 8600 GVW-->Manual-->1 Speed Active	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3-->Under 8600 GVW-->Manual-->2 Speed Active	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3-->Under 8600 GVW-->Manual-->Electronic Shift/Manual Shift	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3-->Under 8600 GVW-->Manual-->2 Wheel Drive	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3-->Equal to or Over 8600 GVW-->4 Speed Automatic-->1 Speed Active	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3-->Equal to or Over 8600 GVW-->4 Speed Automatic-->2 Speed Active	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3-->Equal to or Over 8600 GVW-->4 Speed Automatic-->Electronic Shift/Manual Shift	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3-->Equal to or Over 8600 GVW-->4 Speed Automatic-->2 Wheel Drive	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3-->Equal to or Over 8600 GVW-->Manual-->1 Speed Active	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3-->Equal to or Over 8600 GVW-->Manual-->2 Speed Active	✓	✓	✓	✓	✓

<http://www.autoboss.net>

Autoboss Scanner Function List

[X]	4.3L V6 LU3-->Equal to or Over 8600 GVW-->Manual -->Electronic Shift/Manual Shift	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3-->Equal to or Over 8600 GVW-->Manual -->2 Wheel Drive	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3 (C/K G only)-->Under 8600 GVW-->4 Speed Automatic-->2 Speed Active	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3 (C/K G only)-->Under 8600 GVW-->4 Speed Automatic-->Electronic Shift/Manual Shift	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3 (C/K G only)-->Under 8600 GVW-->4 Speed Automatic-->2 Wheel Drive	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3 (C/K G only)-->Under 8600 GVW-->Manual -->2 Speed Active	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3 (C/K G only)-->Under 8600 GVW-->Manual -->Electronic Shift/Manual Shift	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3 (C/K G only)-->Under 8600 GVW-->Manual -->2 Wheel Drive	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3 (C/K G only)-->Equal to or Over 8600 GVW-->4 Speed Automatic-->2 Speed Active	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3 (C/K G only)-->Equal to or Over 8600 GVW-->4 Speed Automatic-->Electronic Shift/Manual Shift	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3 (C/K G only)-->Equal to or Over 8600 GVW-->4 Speed Automatic-->2 Wheel Drive	✓	✓	✓	✓	✓
[X]	4.3L V6 LU3 (C/K G only)-->Equal to or Over 8600 GVW-->Manual -->2 Speed Active	✓	✓	✓	✓	✓

<http://www.autoboss.net>

Autoboss Scanner Function List

	[X] 4.3L V6 LU3 (C/K G only)-->Equal to or Over 8600 GVW-->Manual -->Electronic Shift/Manual Shift	✓	✓	✓	✓	✓
	[X] 4.3L V6 LU3 (C/K G only)-->Equal to or Over 8600 GVW-->Manual -->2 Wheel Drive	✓	✓	✓	✓	✓
	[V] 4.8L V8 LR4-->4 Speed Automatic-->Without Throttle-actuated Control	✓	✓	✓	✓	✓
	[V] 4.8L V8 LR4-->4 Speed Automatic-->With Throttle-actuated Control	✓	✓	✓	✓	✓
	[V] 4.8L V8 LR4-->Manual	✓	✓	✓	✓	✓
	(M)5.0L V8 L30	✓	✓	✓	✓	✓
	(T) 5.3L V8 LM7	✓	✓	✓	✓	✓
	(Z) 5.3L V8 L59	✓	✓	✓	✓	✓
	(R) 5.7L V8 L31	✓	✓			
	(N) 6.0L V8 LQ9	✓	✓	✓	✓	✓
	[U] 6.0L V8 LQ4-->4 Speed Automatic-->2 Speed Active-->Without Throttle-actuated Control	✓	✓	✓	✓	✓
	[U] 6.0L V8 LQ4-->4 Speed Automatic-->2 Speed Active-->With Throttle-actuated Control	✓	✓	✓	✓	✓
	[U] 6.0L V8 LQ4-->4 Speed Automatic-->Electronic Shift/Manual Shift-->Without Throttle-actuated Control	✓	✓	✓	✓	✓
	[U] 6.0L V8 LQ4-->4 Speed Automatic-->Electronic Shift/Manual Shift-->With Throttle-actuated Control	✓	✓	✓	✓	✓
	[U] 6.0L V8 LQ4-->4 Speed Automatic-->263 NVG Transfer Case-->Without Throttle-actuated Control	✓	✓	✓	✓	✓

<http://www.autoboss.net>

Autoboss Scanner Function List

		[U] 6.0L V8 LQ4-->4 Speed Automatic-->263 NVG Transfer Case-->With Throttle-actuated Control	√	√	√	√	√
		[U] 6.0L V8 LQ4-->4 Speed Automatic-->2 Wheel Drive-->Without Throttle-actuated Control	√	√	√	√	√
		[U] 6.0L V8 LQ4-->4 Speed Automatic-->2 Wheel Drive-->With Throttle-actuated Control	√	√	√	√	√
		[U] 6.0L V8 LQ4-->Manual -->2 Speed Active	√	√	√	√	√
		[U] 6.0L V8 LQ4-->Manual -->Electronic Shift/Manual Shift	√	√	√	√	√
		[U] 6.0L V8 LQ4-->Manual -->263 NVG Transfer Case	√	√	√	√	√
		[U] 6.0L V8 LQ4-->Manual -->2 Wheel Drive	√	√	√	√	√
		(F) 6.5L V8 L65	√	√			
		(I) 6.6L V8 LB7 Diesel	√	√			
		(G) 8.1L V8 L18	√	√			
		(G) 8.1L V8 L18 3500 HD Only	√	√	√	√	√
	Body	[A]	√	√	√		
		[B]	√	√	√		
		[C]	√	√	√		
		[E]	√	√	√		
		[G]	√	√	√		
		[H]	√	√	√		
		[J]	√	√	√		
		[K]	√	√	√		
		[L]	√	√	√		
		[M]	√	√	√		

<http://www.autoboss.net>

Autoboss Scanner Function List

			[S]	✓	✓	✓		
			[T]	✓	✓	✓		
			[U]	✓	✓	✓		
			[V]	✓	✓	✓		
			[X]	✓	✓	✓		
		Chassis	\C\Under 15000 GVW\4WAL 3 Sensor	✓	✓	✓		
			\C\Under 15000 GVW\Traction Assist (If Equipped)	✓	✓	✓		
			\E\4WAL 3 Sensor	✓	✓	✓		
			\H\DRP/ABS/TCS	✓	✓	✓		
			\H\Magna Steer\Diagnostics	✓	✓	✓		
			\H\Rear Integration Module\diagnostics	✓	✓	✓		
			\J\4WAL 3 Sensor	✓	✓	✓		
			\K\4WAL 3 Sensor	✓	✓	✓		
			\K\Electronic Variable Orifice	✓	✓	✓		
			\K\VSES (If Equipped)	✓	✓	✓		
			\L\4WAL 3 Sensor	✓	✓	✓		
			\M\4WAL 3 Sensor	✓	✓	✓		
			\S\4WAL 3 Sensor	✓	✓	✓		
			\S\Traction Assist (If Equipped)	✓	✓	✓		
			\T\4WAL 3 Sensor	✓	✓	✓		
Saturn	Powertrain	[7] 1.9L L4 LL0	✓	✓	✓			
		[8] 1.9L L4 L24	✓	✓	✓			
		[F] 2.2L L4 L61	✓	✓	✓			
	BODY	J	✓	✓	✓			

<http://www.autoboss.net>

Autoboss Scanner Function List

			Z	✓	✓	✓		
		Chassis	Z\S-Series\Electric Power Steering	✓	✓	✓		
2003	Passenger Car	Powertrain	(6) 2.2L L4 L42 Alternative Fuel	✓	✓	✓	✓	✓
			(F) 2.2L L4 L61\J\4 speed Automatic	✓	✓	✓	✓	✓
			(F) 2.2L L4 L61\J\Manual	✓	✓	✓	✓	✓
			(F) 2.2L L4 L61\N\4 speed Automatic	✓	✓	✓	✓	✓
			(F) 2.2L L4 L61\N\Manual	✓	✓	✓	✓	✓
			(J) 3.1L V6 LG8\N	✓	✓	✓	✓	✓
			(J) 3.1L V6 LG8\W\Buick	✓	✓	✓	✓	✓
			(J) 3.1L V6 LG8\W\Pontiac	✓	✓	✓	✓	✓
			(E) 3.4L V6 LA1\N	✓	✓	✓	✓	✓
			(E) 3.4L V6 LA1\W	✓	✓	✓	✓	✓
			(1) 3.8L V6 L67\C	✓	✓	✓	✓	✓
			(1) 3.8L V6 L67\H	✓	✓	✓	✓	✓
			(1) 3.8L V6 L67\W	✓	✓	✓	✓	✓
			(1) 3.8L V6 L67\2 Pontiac	✓	✓	✓	✓	✓
			(1) 3.8L V6 L67\4 Buick	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\C\Without Air Pump	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\C\With Air Pump	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\H\Without Air Pump	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\H\With Air Pump	✓	✓	✓	✓	✓
			(K) 3.8L V6 L36\W\Buick\Without Air Pump	✓	✓	✓	✓	✓
(K) 3.8L V6 L36\W \Buick \With Air Pump	✓	✓	✓	✓	✓			
(K) 3.8L V6 L36\W \Chevrolet \Without Air Pump	✓	✓	✓	✓	✓			
(K) 3.8L V6 L36\W \Chevrolet \With Air Pump	✓	✓	✓	✓	✓			

http: //www.autoboss.net

Autoboss Scanner Function List

		(K) 3.8L V6 L36[W]\Pontic\Without Air Pump	√	√	√	√	√
		(K) 3.8L V6 L36[W] \Pontic \With Air Pump	√	√	√	√	√
		(C) 4.0L V8 L47	√	√	√	√	√
		(9) 4.6L V8 L37	√	√	√	√	√
		(Y) 4.6L V8 LD8	√	√	√	√	√
		(G) 5.7L V8 LS1\4 Speed Automatic	√	√	√	√	√
		(G) 5.7L V8 LS1\Manual	√	√	√	√	√
		(S) 5.7L V8 LS6	√	√	√	√	√
	BODY	[C]	√	√	√	√	√
		[D]	√	√	√	√	√
		[G]	√	√	√	√	√
		[H]	√	√	√	√	√
		[Y]	√	√	√	√	√
		[K]	√	√	√	√	√
		[L]	√	√	√	√	√
		[M]	√	√	√	√	√
		[N]	√	√	√	√	√
		[S]	√	√	√	√	√
		[T]	√	√	√	√	√
		[U]	√	√	√	√	√
		[V]	√	√	√	√	√
		[W]	√	√	√	√	√
	[Y]	√	√	√	√	√	

<http://www.autoboss.net>

Autoboss Scanner Function List

	Chassis	ABS	✓	✓			
LD Trk, MPV , Incomplete	Powertrain	(H)2.2L L4 LN2\4 Speed Automatic	✓	✓	✓	✓	✓
		(H)2.2L L4 LN2\Manual	✓	✓	✓	✓	✓
		(E)3.4L V6 LA1\Without Air Pump\Without All Wheel Drive	✓	✓	✓	✓	✓
		(E)3.4L V6 LA1\Without Air Pump\With All Wheel Drive	✓	✓	✓	✓	✓
		(E)3.4L V6 LA1\With Air Pump\Without All Wheel Drive	✓	✓	✓	✓	✓
		(E)3.4L V6 LA1\With Air Pump\With All Wheel Drive	✓	✓	✓	✓	✓
		(P) 3.9L L4 L4B Diesel	✓	✓	✓	✓	✓
		(S) 4.2L L6 LL8\4 Speed Automatic\1 Speed Active	✓	✓	✓	✓	✓
		(S) 4.2L L6 LL8\4 Speed Automatic\2 Speed Active	✓	✓	✓	✓	✓
		(S) 4.2L L6 LL8\4 Speed Automatic\2 Wheel Drive	✓	✓	✓	✓	✓
		(W) 4.3L V6 L35\4 Speed Automatic\Equal to or Over 8600 GVW	✓	✓	✓	✓	✓
		(W) 4.3L V6 L35\Manual\Equal to or Over 8600 GVW	✓	✓	✓	✓	✓
		(X) 4.3L V6 LU3	✓	✓			✓
		(X) 4.3L V6 LU3 (G Van)\ Automatic	✓	✓	✓	✓	✓
		(X) 4.3L V6 LU3 (C/K, only)\ 4 Speed Automatic\2 Speed Active	✓	✓	✓	✓	✓
		(X) 4.3L V6 LU3 (C/K, only)\ 4 Speed Automatic\Electronic Shift/Manual Shift	✓	✓	✓	✓	✓
		(X) 4.3L V6 LU3 (C/K, only)\ 4 Speed Automatic\2 Wheel Drive	✓	✓	✓	✓	✓
		(X) 4.3L V6 LU3 (C/K, only)\ 4 Speed Manual\2 Speed Active	✓	✓	✓	✓	✓
(X) 4.3L V6 LU3 (C/K, only)\ 4 Speed Manual\2 Wheel Drive	✓	✓	✓	✓	✓		
(V) 4.8L V8 LR4\4 Speed Automatic\Under 8600 GVW\2 Speed Active	✓	✓	✓	✓	✓		

<http://www.autoboss.net>

Autoboss Scanner Function List

	(V) 4.8L V8 LR4\4 Speed Automatic\Under 8600 GVW\Electronic Shift/Manual Shift	√	√	√	√	√
	(V) 4.8L V8 LR4\4 Speed Automatic\Under 8600 GVW\2 Wheel Drive	√	√	√	√	√
	(V) 4.8L V8 LR4\4 Speed Automatic\Equal to or Over 8600 GVW\2 Speed Active\Without Throttle-actuated Control	√	√	√	√	√
	(V) 4.8L V8 LR4\4 Speed Automatic\Equal to or Over 8600 GVW\2 Speed Active\With Throttle-actuated Control	√	√	√	√	√
	(V) 4.8L V8 LR4\4 Speed Automatic\Equal to or Over 8600 GVW\Electronic Shift/Manual Shift\Without Throttle-actuated Control	√	√	√	√	√
	(V) 4.8L V8 LR4\4 Speed Automatic\Equal to or Over 8600 GVW\Electronic Shift/Manual Shift\With Throttle-actuated Control	√	√	√	√	√
	(V) 4.8L V8 LR4\4 Speed Automatic\Equal to or Over 8600 GVW\2 Wheel Drive\Without Throttle-actuated Control	√	√	√	√	√
	(V) 4.8L V8 LR4\4 Speed Automatic\Equal to or Over 8600 GVW\2 Wheel Drive\With Throttle-actuated Control	√	√	√	√	√
	(V) 4.8L V8 LR4\Manual\2 Speed Active	√	√	√	√	√
	(V) 4.8L V8 LR4\Manual\2 Wheel Drive	√	√	√	√	√
	(P) 5.3L V8 LM4\2 Speed Active\Envog XL	√	√	√	√	√
	[P] 5.3LV8 LM4\2 Speed Active\TrailBlazer EXT	√	√	√	√	√
	(P) 5.3L V8 LM4\2 Speed Active\SSR	√	√	√	√	√
	(P) 5.3L V8 LM4\2 Speed Active\SSR	√	√	√	√	√
	(P) 5.3L V8 LM4\2 Wheel Drive\Envog XL	√	√	√	√	√

<http://www.autoboss.net>

Autoboss Scanner Function List

	(P) 5.3L V8 LM4\2 Wheel Drive\TrailBlazer EXT	✓	✓	✓	✓	✓
	(P) 5.3L V8 LM4\2 Wheel Drive\SSR	✓	✓	✓	✓	✓
	(T) 5.3L V8 LM7\4 Speed Automatic\Under 8600 GVW\2 Speed Active\Without Throttle-actuated Control	✓	✓	✓	✓	✓
	(T) 5.3L V8 LM7\4 Speed Automatic\Under 8600 GVW\2 Speed Active\With Throttle-actuated Control	✓	✓	✓	✓	✓
	(T) 5.3L V8 LM7\4 Speed Automatic\Under 8600 GVW\AWD\Without Throttle-actuated Control	✓	✓	✓	✓	✓
	(T) 5.3L V8 LM7\4 Speed Automatic\Under 8600 GVW\AWD\With Throttle-actuated Control	✓	✓	✓	✓	✓
	(T) 5.3L V8 LM7\4 Speed Automatic\Under 8600 GVW\BorgWarner\Without Throttle-actuated Control	✓	✓	✓	✓	✓
	(T) 5.3L V8 LM7\4 Speed Automatic\Under 8600 GVW\BorgWarner\With Throttle-actuated Control	✓	✓	✓	✓	✓
	(T) 5.3L V8 LM7\4 Speed Automatic\Under 8600 GVW\Avalanche\Envoy\Without Throttle-actuated Control	✓	✓	✓	✓	✓
	(T) 5.3L V8 LM7\4 Speed Automatic\Under 8600 GVW\Avalanche\Envoy\With Throttle-actuated Control	✓	✓	✓	✓	✓
	(T) 5.3L V8 LM7\4 Speed Automatic\Under 8600 GVW\2 Wheel Drive\Without Throttle-actuated Control	✓	✓	✓	✓	✓
	(T) 5.3L V8 LM7\4 Speed Automatic\Under 8600 GVW\2 Wheel Drive\With Throttle-actuated Control	✓	✓	✓	✓	✓
	(T) 5.3L V8 LM7\4 Speed Automatic\Equal to or Over 8600 GVW\2 Speed Active\Without Throttle-actuated Control	✓	✓	✓	✓	✓

<http://www.autoboss.net>

Autoboss Scanner Function List

	(T) 5.3L V8 LM7\4 Speed Automatic\Equal to or Over 8600 GVW\2 Speed Active\With Throttle-actuated Control	√	√	√	√	√
	(T) 5.3L V8 LM7\4 Speed Automatic\Equal to or Over 8600 GVW\Electronic Shift/Manual Shift\Without Throttle-actuated Control	√	√	√	√	√
	(T) 5.3L V8 LM7\4 Speed Automatic\Equal to or Over 8600 GVW\Electronic Shift/Manual Shift\With Throttle-actuated Control	√	√	√	√	√
	(T) 5.3L V8 LM7\4 Speed Automatic\Equal to or Over 8600 GVW\BorgWarner\Without Throttle-actuated Control	√	√	√	√	√
	(T) 5.3L V8 LM7\4 Speed Automatic\Equal to or Over 8600 GVW\BorgWarner\With Throttle-actuated Control	√	√	√	√	√
	(T) 5.3L V8 LM7\4 Speed Automatic\Equal to or Over 8600 GVW\2 Wheel Drive\Without Throttle-actuated Control	√	√	√	√	√
	(T) 5.3L V8 LM7\4 Speed Automatic\Equal to or Over 8600 GVW\2 Wheel Drive\With Throttle-actuated Control	√	√	√	√	√
	(Z) 5.3L V8 L59\4 Speed Automatic\2 Speed Active	√	√	√	√	√
	(Z) 5.3L V8 L59\4 Speed Automatic\BorgWarner	√	√	√	√	√
	(Z) 5.3L V8 L59\4 Speed Automatic\2 Wheel Drive	√	√	√	√	√
	(R) 5.7L V8 L31	√	√			
	(N) 6.0L V8 LQ9	√	√	√	√	√
	(U) 6.0L V8 LQ4\4 Speed Automatic\Under 8600 GVW\2 Speed Active\With Throttle-actuated Control	√	√	√	√	√
	(U) 6.0L V8 LQ4\4 Speed Automatic\Under 8600 GVW\AWD\With Throttle-actuated Control	√	√	√	√	√

<http://www.autoboss.net>

Autoboss Scanner Function List

		(U) 6.0L V8 LQ4\4 Speed Automatic\Under 8600 GVW\BorgWarner\With Throttle-actuated Control	√	√	√	√	√
		(U) 6.0L V8 LQ4\4 Speed Automatic\Under 8600 GVW\263 NVG Transfer Case\With Throttle-actuated Control	√	√	√	√	√
		(U) 6.0L V8 LQ4\4 Speed Automatic\Equal to or Over 8600 GVW\2 Speed Active\Without Throttle-actuated Control	√	√	√	√	√
		(U) 6.0L V8 LQ4\4 Speed Automatic\Equal to or Over 8600 GVW\2 Speed Active\With Throttle-actuated Control	√	√	√	√	√
		(U) 6.0L V8 LQ4\4 Speed Automatic\Equal to or Over 8600 GVW\Electronic Shift/Manual Shift\Without Throttle-actuated Control	√	√	√	√	√
		(U) 6.0L V8 LQ4\4 Speed Automatic\Equal to or Over 8600 GVW\Electronic Shift/Manual Shift\With Throttle-actuated Control	√	√	√	√	√
		(U) 6.0L V8 LQ4\4 Speed Automatic\Equal to or Over 8600 GVW\BorgWarner\Without Throttle-actuated Control	√	√	√	√	√
		(U) 6.0L V8 LQ4\4 Speed Automatic\Equal to or Over 8600 GVW\BorgWarner\With Throttle-actuated Control	√	√	√	√	√
		(U) 6.0L V8 LQ4\4 Speed Automatic\Equal to or Over 8600 GVW\263 NVG Transfer Case\Without Throttle-actuated Control	√	√	√	√	√
		(U) 6.0L V8 LQ4\4 Speed Automatic\Equal to or Over 8600 GVW\263 NVG Transfer Case\With Throttle-actuated Control	√	√	√	√	√
		(U) 6.0L V8 LQ4\4 Speed Automatic\Equal to or Over 8600 GVW\2 Wheel Drive\Without Throttle-actuated Control	√	√	√	√	√

<http://www.autoboss.net>

Autoboss Scanner Function List

	(U) 6.0L V8 LQ4\4 Speed Automatic\Equal to or Over 8600 GVW\2 Wheel Drive\With Throttle-actuated Control	✓	✓	✓	✓	✓
	(U) 6.0L V8 LQ4\Manual\2 Speed Active	✓	✓	✓	✓	✓
	(U) 6.0L V8 LQ4\Manual\Electronic Shift/Manual Shift	✓	✓	✓	✓	✓
	(U) 6.0L V8 LQ4\Manual\BorgWarner	✓	✓	✓	✓	✓
	(U) 6.0L V8 LQ4\Manual\263 NVG Transfer Case	✓	✓	✓	✓	✓
	(U) 6.0L V8 LQ4\Manual\2 Wheel Drive	✓	✓	✓	✓	✓
	(F) 6.5L V8 L65\4 Speed Automatic	✓	✓			✓
	(1) 6.6L V8 LB7 Diesel\5 Speed Automatic\California Emissions\263 NVG Transfer	✓	✓	✓	✓	✓
	(1) 6.6L V8 LB7 Diesel\5 Speed Automatic\California Emissions\2 Wheel Drive	✓	✓	✓	✓	✓
	(1) 6.6L V8 LB7 Diesel\5 Speed Automatic\Federal Emissions\263 NVG Transfer	✓	✓	✓	✓	✓
	(1) 6.6L V8 LB7 Diesel\5 Speed Automatic\Federal Emissions\2 Wheel Drive	✓	✓	✓	✓	✓
	(1) 6.6L V8 LB7 Diesel\Manual\Federal Emissions\263 NVG Transfer	✓	✓	✓	✓	✓
	(1) 6.6L V8 LB7 Diesel\Manual\Federal Emissions\2 Wheel Drive	✓	✓	✓	✓	✓
	(1) 6.6L V8 LB7 Diesel\Manual\California Emissions\263 NVG Transfer	✓	✓	✓	✓	✓
	(1) 6.6L V8 LB7 Diesel\Manual\California Emissions\2 Wheel Drive	✓	✓	✓	✓	✓
	(G) 8.1L V8 L18\4 Speed Automatic\2 Speed Active	✓	✓	✓	✓	✓

<http://www.autoboss.net>

Autoboss Scanner Function List

		(G) 8.1L V8 L18\4 Speed Automatic\263 NVG Transfer Case	✓	✓	✓	✓	✓
		(G) 8.1L V8 L18\4 Speed Automatic\2 Wheel Drive	✓	✓	✓	✓	✓
		(G) 8.1L V8 L18\5 Speed Automatic\2 Speed Active	✓	✓	✓	✓	✓
		(G) 8.1L V8 L18\5 Speed Automatic\263 NVG Transfer Case	✓	✓	✓	✓	✓
		(G) 8.1L V8 L18\5 Speed Automatic\2 Wheel Drive	✓	✓	✓	✓	✓
		(G) 8.1L V8 L18\Manual\2 Speed Active	✓	✓	✓	✓	✓
		(G) 8.1L V8 L18\Manual\263 NVG Transfer Case	✓	✓	✓	✓	✓
		(G) 8.1L V8 L18\Manual\2 Wheel Drive	✓	✓	✓	✓	✓
		Alternative Fuels \[U] 6.0L LQ4 Bi-Fuel	✓	✓	✓	✓	✓
		Alternative Fuels\[U] 6.0L LQ4 Bi-Fuel G van	✓	✓	✓	✓	✓
		Alternative Fuels\[U] 6.0L LQ4 Dedicated G van	✓	✓	✓	✓	✓
	Body	[A]	✓	✓	✓		
		[B]	✓	✓	✓		
		[C]	✓	✓	✓		
		[E]	✓	✓	✓		
		[G]	✓	✓	✓		
		[H]	✓	✓	✓		
		[J]	✓	✓	✓		
		[K]	✓	✓	✓		
		[L]	✓	✓	✓		
		[M]	✓	✓	✓		
		[S]	✓	✓	✓		
		[T]	✓	✓	✓		
		[U]	✓	✓	✓		
		[V]	✓	✓	✓		

<http://www.autoboss.net>

Autoboss Scanner Function List

		[X]	✓	✓	✓		
		[N]	✓	✓	✓		
	Chassis	\C\Equal to or Under 8600 GVW\ABS	✓	✓	✓		
		\C\Equal to or Under 8600 GVW\ESC (If Equipped)	✓	✓	✓		
		\C\Equal to or Under 8600 GVW\Rear Wheel Steering	✓	✓	✓		
		\C\Equal to or Under 8600 GVW\Traction Assist (If Equipped)	✓	✓	✓		
		\C\Equal to or Under 8600 GVW\VSES (If Equipped)	✓	✓	✓		
		\C\Over 8600 GVW\ABS	✓	✓	✓		
		\C\Over 8600 GVW\ESC (If Equipped)	✓	✓	✓		
		\C\Over 8600 GVW\Rear Wheel Steering	✓	✓	✓		
		\E\4WAL 3 Sensor	✓	✓	✓		
		\G(C)\Chevrolet Truck\ABS	✓	✓	✓		
		\G(T)\GMC Truck\ABS	✓	✓	✓		
		\H(C)\Chevrolet Truck\ABS	✓	✓	✓		
		\H(T)\GMC Truck\ABS	✓	✓	✓		
		\H(E)\Cadillac Incomplete\Hearse\DRP/ABS/TCS	✓	✓	✓		
		\H(E)\Cadillac Incomplete\Hearse\Magna Steer\Diagnostics	✓	✓	✓		
		\H(E)\Cadillac Incomplete\Hearse\Rear Integration Module\Diagnostics	✓	✓	✓		
		\H(E)\Cadillac Incomplete\Limousine\DRP/ABS/TCS	✓	✓	✓		
		\H(E)\Cadillac Incomplete\Limousine\Magna Steer\Diagnostics	✓	✓	✓		
		\H(E)\Cadillac Incomplete\Limousine\Rear Integration Module\Diagnostics	✓	✓	✓		
		\J\4WAL 3 Sensor	✓	✓	✓		
		\K\Equal to or Under 8600 GVW\ABS	✓	✓	✓		

<http://www.autoboss.net>

Autoboss Scanner Function List

			\K\Equal to or Under 8600 GVW\ESC (If Equipped)	✓	✓	✓		
			\K\Equal to or Under 8600 GVW\Rear Wheel Steering	✓	✓	✓		
			\K\Equal to or Under 8600 GVW\VSES (If Equipped)	✓	✓	✓		
			\K\Over 8600 GVW\ABS	✓	✓	✓		
			\K\Over 8600 GVW\ESC (If Equipped)	✓	✓	✓		
			\K\Over 8600 GVW\Rear Wheel Steering	✓	✓	✓		
			\L\4WAL 3 Sensor	✓	✓	✓		
			\M\4WAL 3 Sensor	✓	✓	✓		
			\N\ABS	✓	✓	✓		
			\N\Air Suspension	✓	✓	✓		
			\S\4WAL 3 Sensor	✓	✓	✓		
			\S\Traction Assist (If Equipped)	✓	✓	✓		
			\T\4WAL 3 Sensor	✓	✓	✓		
			Saturn	Powertrain				
BODY	A	✓			✓	✓		
	J	✓		✓	✓			
	Z	✓		✓	✓			
Chassis	A\ABS	✓		✓	✓			
	A\Antilock Brake System	✓		✓	✓			
	A\Electric Power Steering	✓		✓	✓			
	Z\Electric Power Steering	✓	✓	✓				

<http://www.autoboss.net>