

Basic Function List

LEXUS

Autoboss Scanner: V30

Version: V2.8

Date: 2009-07-07

Connector	Model Year	Canbus System	Read DTC	Erase DTC	Data Stream	Actuation Test	Special Function
[OBD-16] CANBUS	-2008	Engine and ECT	✓	✓	✓	✓	MATCH ECU
	-2008	Cruise Control	✓	✓	✓		
	-2008	Engine	✓	✓	✓	✓	MATCH ECU
	-2008	Hybrid Control	✓	✓	✓	✓	
	-2008	Radar Cruise I	✓	✓	✓		
	-2008	Laser Cruise	✓	✓	✓		
	-2008	ECT	✓	✓	✓	✓	
	-2008	Multi-Mode M/T	✓	✓	✓	✓	
	-2008	HV Battery	✓	✓	✓	✓	
	-2008	Radar Cruise II	✓	✓	✓		
	-2008	E-ACM	✓	✓	✓	✓	
	-2008	ABS	✓	✓	✓	✓	
	-2008	Four Wheel Drive	✓	✓	✓	✓	

SPX AUTOBOSS TECH. INC.
Autoboss Scanner Function List

	-2008	EMPS	✓	✓	✓		
	-2008	Intelligent Parking Assist	✓	✓	✓		
	-2008	SRS Airbag	✓	✓			
	-2008	Pre-Crash	✓	✓		✓	
	-2008	Combination Meter	✓	✓		✓	
	-2008	Electric Power Control	✓	✓	✓	✓	
	-2008	Air Conditioner	✓	✓	✓	✓	Compass calibration

Connector	Model Year	System	Read DTC	Erase DTC	Data Stream	Actuation Test	Special Function
[TOYOTA-17]	-1997	ENGINE	✓	Manual	✓		MATCH ECU
		A/T	✓	Manual			
		AIRBAG	✓	Manual			
		ECT	✓	Manual			
		ABS	✓	Manual			
		CCS	✓	Manual			
[TOYOTA-22]	-1997	ENGINE	✓	Manual	✓		
		AIRBAG	✓	Manual			
[OBD-16]	-2004	ENGINE AND ECT	✓	✓	✓	✓	ECU RESET MATCH ECU
		Engine	✓	✓	✓		
		ABS/VSC/TRAC	✓	✓	✓	✓	ECU RESET TEST MODE

SPX AUTOBOSS TECH. INC.
Autoboss Scanner Function List

		AHC	✓	✓	✓	✓	
		EMPS/EHPS	✓	✓	✓		Torque Sensor Adjustment
		FREE-TRONIC	✓	✓	✓		
		TIRE PRESSURE	✓	✓	✓		
		SRS AIRBAG	✓	✓			
		AIR CONDITIONER	✓	✓	✓	✓	1.Compass calibration 2.Servomotor Initialization
		BACK-DOOR		✓	✓	✓	
		BODY	✓	✓	✓	✓	
		BODY(FOR Lexus)	✓	✓	✓	✓	
		BODY NO.2			✓	✓	
		BODY NO.2 (For LS430/SC430)			✓		
		BODY NO.3	✓		✓	✓	
		BODY NO.3 (For CROWN)			✓	✓	
		BODY NO.4	✓	✓	✓	✓	
		BODY NO.5			✓	✓	
		CLEARANCE SONAR		✓	✓	✓	
		COMBI SW			✓		
		D-DOOR	✓	✓	✓	✓	
		P-DOOR	✓	✓	✓	✓	
		RR-DOOR	✓	✓	✓	✓	

SPX. AUTOBOSS TECH. INC.
Autoboss Scanner Function List

		RL-DOOR	✓	✓	✓	✓	
		D-SEAT			✓	✓	
		P-SEAT			✓	✓	
		RR-SEAT			✓	✓	
		RL-SEAT			✓	✓	
		REAR SEAT SW			✓		
		GATEWAY	✓	✓			
		METER			✓	✓	
		MIRROR			✓	✓	
		RAIN SENSOR			✓		
		RTRCTBL HARDTOP	✓	✓	✓	✓	
		SLIDE ROOF			✓		
		STEERING PAD			✓		
		TILT&TELESCO	✓	✓	✓	✓	
		AFS		✓	✓	✓	
		MASTER SW			✓	✓	
		CCS	✓	✓	✓		
		HV BATTERY	✓	✓	✓	✓	
		HV ECU	✓	✓			
		EV	✓	✓	✓	✓	
		EV BATTERY	✓	✓	✓	✓	
		STOP AND GO	✓	✓	✓	✓	

SPX. AUTOBOSS TECH. INC.
Autoboss Scanner Function List

		SEQUENTIAL MT	✓	✓	✓	✓	
		LASER CRUISE		✓	✓		
		IMMOBILIER	✓	✓	✓		Registration KEY Erasure KEY
		STEERING LOCK	✓	✓	✓	✓	Registration KEY Erasure KEY
		TDS	✓	✓	✓	✓	
		AIR SUSPENSION	✓	✓	✓	✓	
		BATTERY	✓	✓	✓	✓	
		KDSS	✓	✓	✓	✓	
		TM	✓	✓	✓		
		VGRS	✓	✓	✓		

Note:

✓: function is supported

*: Newly added function

✖: function is in progress (not recommended)

△: Not applicable.

○: Not available at the moment.