

**Function List**

**Mitsubishi**

Autoboss Scanner: V30

Version: V4.2

Date: 2009-05-06

Protocol	Area	Year	System	ID Info	Read DTC	Erase DTC	Data List	Actuator Test	Special Function
<b>Without CANBUS</b>	<b>Asian</b>	<b>-2008</b>	MPI/GDI/DIESEL	√	√	√	√	√	
			ELC-AT/CVT	√	√	√	√	√	
			ABS/ASC/ASTC	√	√	√	√	√	
			SRS-AIR BAG	√	√	√	√		
			Air Conditioner	√	√	√	√	√	
			ECS	√	√	√	√		
			IMMOBILIZER	√	√	√	√	√	Key Program
			AUTO CRUISE	√	√	√	√		
			TCL/STABILITY CONTROL	√	√	√	√	√	
			4WS/Electric Power Steering	√	√	√	√	√	
			SS4 II	√	√	√	√	√	
			HBB	√	√	√	√	√	
	AYC/ACD	√	√	√	√	√			
	<b>European/</b>	<b>-2008</b>	MPI/GDI/DIESEL	√	√	√	√	√	

**SPX** AUTOBOSS TECH. INC.  
**Autoboss Scanner Function List**

	<b>American</b>		ELC-AT/CVT	√	√	√	√	√	
			ABS/ASC/ASTC	√	√	√	√	√	
			SRS-AIR BAG	√	√	√	√		
			Air Conditioner	√	√	√	√	√	
			ECS	√	√	√	√		
			IMMOBILIZER	√	√	√	√	√	Key Program
			AUTO CRUISE	√	√	√	√		
			TCL/STABILITY CONTROL	√	√	√	√	√	
			4WS/Electric Power Steering	√	√	√	√	√	
			SS4 II	√	√	√	√	√	
			HBB	√	√	√	√	√	
			AYC/ACD	√	√	√	√	√	
<b>With CANBUS</b>	<b>EUR / EXP / JAPAN / MMAL / MMNA</b>	<b>2005 To 2008</b>	MPI/GDI/DIESEL	√	√	√	√	√	
			ELC-AT/CVT	√	√	√	√	√	
			ABS/ASC/ASTC	√	√	√	√	√	
			SRS-AIR BAG	√	√	√	√	√	
			Air Conditioner	√	√	√	√	√	
			IMMOBILIZER	√	√	√	√		
			AUTO CRUISE	√	√	√	√		
			TCL/STABILITY CONTROL	√	√	√	√	√	
			4WS/Electric Power Steering	√	√	√	√	√	
			ETACS	√	√	√	√	√	

**SPX. AUTOBOSS TECH. INC.**  
**Autoboss Scanner Function List**

			Meter	√	√	√	√	√	
			Display	√	√	√		√	
			Steering Angle Sensor	√	√	√			
			Multi Select 4WD	√	√	√			
			Power Gate	√	√	√			
			Keyless Operation	√	√	√			