

Base Function List – NISSAN&INFINITI

Autoboss Scanner: V30

Version: V2.99

Date: 2009-07-08

Base Function List

NISSAN SYSTEM	PROTOCOL MODE	READ DTC	ERASE DTC	DATA STREAM	ACTIVE TEST	ECU NO	WORK SUPPORT
BCM(CAN)	CAN BUS	√	√	√	√	√	√
ALL MODE AWD/4WD(CAN)	CAN BUS	√	√	√	△	△	
AUTO DRIVE POS(CAN)	CAN BUS	√	√	√	√	√	△
ATUO SLIDE DOOR(CAN)	CAN BUS	√	√	√	√	√	△
EPS(CAN)	CAN BUS	√	√	√	△	△	√
INTELLIGENT KEY(CAN)	CAN BUS	√	√	√	√	√	○
IPDM E/R(CAN)	CAN BUS	√	√	√	√	△	△
LDW(CAN)	CAN BUS	√	√	√	√	√	○
Meter(CAN)	CAN BUS	√	√	√	△	△	△
METER A/C AMP(CAN)	CAN BUS	√	√	√	√	△	△
MULTIAV(CAN)	CAN BUS	√	√	√	△	√	△
ADAPTIVE LIGHT (CAN)	CAN BUS	√	√	√	√	√	√
AIR PRESSURE MONITOR(CAN)	CAN BUS	√	√	√	√	√	√
DIU(CAN)	CAN BUS	√	√	√	△	√	△
e-4WD (CAN)	CAN BUS	√	√	√	√	√	△
ENGINE(CAN)	CAN BUS	√	√	√	√	△	○
HICAS-4WS(CAN) (CAN)	CAN BUS	√	√	√	√	√	△

SPX. AUTOBOSS TECH. INC.
Autoboss Scanner Function List

HVAC(CAN)	CAN BUS	✓	✓	✓	△	✓	△
ICC (CAN)	CAN BUS	✓	✓	✓	○	✓	○
ABS(CAN)	CAN BUS	✓	✓	✓	○	△	○
PRECRASH SEATBELT (CAN)	CAN BUS	✓	✓	✓	△	✓	△
TRANSMISSION (CAN)	CAN BUS	✓	✓	✓	○	✓	○
ENGINE SYSTEM	KWP	✓	✓	✓	✓	✓	✓
ENGINE SYSTEM	KWP	✓	✓	✓	✓	✓	✓
A/T SYSTEM	KWP	✓	✓	✓	✓	✓	✓
ABS SYSTEM	KWP	✓	✓	✓	✓	✓	
BCM SYSTEM	KWP	✓	✓	✓	✓	✓	✓
AIRBAG SYSTEM	KWP	✓	✓			✓	
HCM	KWP	✓	✓	✓		✓	
EPS	KWP	✓	✓				
IPDM E/R	KWP	✓	✓				
HEAD LAMP LEVELIZER	KWP	✓	✓		✓		✓
INTELLIGENT KEY	KWP	✓	✓				
AUTO DRIVE POS	KWP	✓	✓				
ADAPTIVE LIGHT	KWP	✓	✓	✓	✓	✓	✓
SMART ENTRANCE	NISSAN	✓	✓	✓	✓	✓	✓
IVMS SYSTEM	NISSAN	✓	✓	✓	✓	✓	
AIRBAG SYSTEM	NISSAN	✓	✓			✓	
ACT D/SUS SYSTEM	NISSAN	✓	✓	✓		✓	
HICAS SYSTEM	NISSAN	✓	✓	✓	✓	✓	
ABS SYSTEM	NISSAN	✓	✓	✓		✓	
ALL MODE 4WD SYSTEM	NISSAN	✓	✓	✓	✓	✓	✓
CVT SYSTEM	NISSAN	✓	✓	✓	✓	✓	✓

SPX. AUTOBOSS TECH. INC.
Autoboss Scanner Function List

A/T SYSTEM	NISSAN	√	√	√			
ASCD SYSTEM	NISSAN	√	√	√			
ENGINE SYSTEM	NISSAN	√	√	√	√	√	√
ENGINE SYSTEM	NISSAN	√	√	√	√	√	√

Notes:

√ : Function Is Supported.

△ : Not Applicable.

○ : Not Available At The Moment.